

S2-PROGBOX

Programming Box



Bansbach
easylift®

FUNCTIONS OF S2-PROGBOX

LOAD & EDIT

This will pick up the parameters from the driver unit. Parameters will be displayed and you can scroll and edit those with S2-PROGBOX. After editing a value, it will blink three times before it is valid.

NOTE: Edited parameter list is only in RAM until you save. After saving (pressing 2sec save button) new edited parameters will be sent to driver unit and stocked in to selected memory slots of the S2-PROGBOX Interface unit.

COPY TO DEVICE

This command will send the parameter list in selected slot in to the driver unit.

MONITOR VALUES

This will enable user to monitor some dynamic values during the use of the driver. Monitorable values can be scrolled with arrow buttons.

MEMORY

* **Show selected** — From here you can see the parameter list which is stored in the slot which is selected at the time.

First you get a message, which slot is selected and for what product the parameters are. Then you are displayed the parameters, which you can scroll through, but not edit until those are saved.

* **Select slot** — Here you choose which one of the 5 memory slots is active. When you save, copy, or go to “Show selected”, the operation is referred to the slot you have chosen here.

SAVING


1. In “Load & Edit” press “2 sec save” button. The displayed parameters (edited or not) will be sent to the driver device and saved to the interface units active slot.
2. “Copy to device” will send the parameters that are in the interface units active slot to the driver device.
3. In all other situations, pressing “2 sec save” button will send the parameters from active slot to driver unit.

NOTE: If you by mistake leave from the “Load & Edit” window with out saving the edited parameters. The edits will stay there if you dont do any saving or copying, or you dont un plug the supply.

To save edited parameters you have to go back to “Load & Edit” and push “2 sec save” button. Then the edited parameters are saved to active slot and sent to the driver device.

START UP

Interface unit is started up by connecting it to a powered driver unit



The menu map of S2-PROGBOX Interface Unit

Note: This unit is for parameter setting of various products, but in examples we have used the code S2-2 as target device

Bansbach Easylift®

50 West Drive
Melbourne, FL 32904

Tel: (321) 253-1999
Fax: (321) 253-5546

sales@easylift.com
www.easylift.com

Bansbach
easylift®

The brochure is subject to technical alterations and printing mistakes.