

R105 Industrial Router



User Manual

Version: 1.2

© Vantron Technology, Inc. All rights reserved.

Revision History:

No.	Software Version	Description	Date
V1.0	V200R003	First release	Jun. 2, 2023
V1.1	V200R003	1. Deleted Firewall zone related description as per design change; 2. Added blacklist and whitelist description to the Firewall section.	Apr. 4, 2023
V1.2	V200R004	1. Modified Overview menu description; 2. Deleted Quick Start for networking; 3. Modified Auto routing description; 4. Updated 4G/LTE description; 5. Added Diagnostic description; 6. Added IPSec setup description.	Jul. 11, 2023

Table of Contents

Foreword	1
CHAPTER 1 HARDWARE DESCRIPTION	5
1.1 Product Overview	6
1.2 Unpackaging	7
1.3 Specifications	8
1.4 Definition of Interfaces	9
1.4.1 Front view	9
1.4.2 Left side view	11
1.4.3 Right side view	12
1.4.4 Back view	12
1.5 Serial Port Description	13
CHAPTER 2 GETTING STARTED	14
2.1 Setting up the Router	15
2.2 Router Login	19
2.3 Password Change	20
2.4 Language Change	20
2.5 Interfacing with Vantron Gateway Management Platform	21
CHAPTER 3 ROUTER SETUP VIA VANTRONOS	22
3.1 Introduction to VantronOS	23
3.2 Status	24
3.3 Quick Start— Auto Routing	26
3.4 Virtual Tunnel	29
3.4.1 OpenVPN Server	29
3.4.2 VPN Client	31
3.5 IPSec Connection	32
3.5.1 Prerequisites	32
3.5.2 Certificate Setup	33
3.5.3 Secret Setup	35
3.5.4 IPSec Connection Setup	37
3.6 Network	60
3.6.1 Interfaces	60
LAN	61
WAN	64
3.6.2 Wireless (WIFI)	68
Wi-Fi – AP Mode (General settings)	68
Wi-Fi – AP Mode (Advanced setting)	69
Wi-Fi – Client Mode	70
Wi-Fi – AP + Client Mode	71
3.6.3 4G/LTE	72
3.6.4 Static Routes	75
3.6.5 Firewall	77
3.7 Diagnostics	82
3.8 VTShark	82

3.9	User Management.....	85
3.10	Customization.....	86
3.10.1	Custom Program.....	86
3.10.2	IPK Installer.....	87
3.10.3	Manufacturer Info Customization	88
3.10.4	DMP Agent	89
3.11	Hardware	90
3.11.1	Ser2TCP	90
3.11.2	Ser2net Environment Setup and Verification	90
3.11.3	Protocol comparison	96
3.12	Services	97
3.12.1	Dynamic DNS.....	97
3.12.2	RC to PLC	97
3.13	System	99
3.13.1	System	99
3.13.2	Netlink Bandwidth Monitor (NBM) Setting	101
3.13.3	Administration.....	103
	SSH Access	103
3.13.4	Terminal.....	105
3.13.5	Mount Points.....	106
3.13.6	Backup/Flash Firmware	108
3.13.7	Reboot.....	111
3.14	Logout	111
CHAPTER 4	DISPOSAL AND PRODUCT WARRANTY	112
4.1	Disposal	113
4.2	Warranty.....	114
Appendix	Regulatory Compliance Statement	115

Foreword

Thank you for purchasing R105 Industrial Router (“the Router” or “the Product”). This manual intends to provide guidance and assistance necessary on setting up, operating or maintaining the Product. Please read this manual and make sure you understand the structure and functionality of the Product before putting it into use.

Intended Users

This manual is intended for:

- Network architects
- Network administrators
- Technical support engineers
- Other users

Copyright

Vantron Technology, Inc. (“Vantron”) reserves all rights of this manual, including the right to change the content, form, product features, and specifications contained herein at any time without prior notice. An up-to-date version of this manual is available at www.vantrontech.com.

The trademarks in this manual, registered or not, are properties of their respective owners. Under no circumstances shall any part of this user manual be copied, reproduced, translated, or sold. This manual is not intended to be altered or used for other purposes unless otherwise permitted in writing by Vantron. Vantron reserves the right of all publicly released copies of this manual.

Disclaimer

While all information contained herein has been carefully checked to assure its accuracy in technical details and typography, Vantron does not assume any responsibility resulting from any error or features of this manual, nor from improper uses of this manual or the software.

It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without notice.

Technical Support and Assistance

Should you have any question about the Product that is not covered in this manual, contact your sales representative for solution. Please contain the following information in your question:

- Product name and PO number;
- Complete description of the problem;
- Error message you received, if any.

Vantron Technology, Inc.

Address: 48434 Milmont Drive, Fremont, CA 94538

Tel: (650) 422-3128

Email: sales@vantrontech.com

Regulatory Information



The Product is designed to comply with:

- Part 15 of the FCC Rules
- IC
- PTCRB

Please refer to **Appendix** for Regulatory Compliance Statement.

Symbology

This manual uses the following signs to prompt users to pay special attention to relevant information.

	Caution for latent damage to system or harm to personnel
	Attention to important information or regulations

General Safety Instructions

The Product is supposed be installed by knowledgeable, skilled persons familiar with local and/or international electrical codes and regulations. For your safety and prevention of damage to the Product and other equipment connected to it, please read and observe carefully the following safety instructions prior to installation and operation. Keep this manual well for future reference.

- Do not disassemble or otherwise modify the Product. Such action may cause heat generation, ignition, electronic shock, or other damages including human injury, and may void your warranty.
- Keep the Product away from heat source, such as heater, heat dissipater, or engine casing.
- Do not insert foreign materials into any opening of the Product as it may cause the Product to malfunction or burn out.
- To ensure proper functioning and prevent overheating of the Product, do not cover or block the ventilation holes of the Product.
- Follow the installation instructions with the installation tools provided or recommended.
- The use or placement of the operation tools shall comply with the code of practice of such tools to avoid short circuit of the Product.
- Cut off the power before inspection of the Product to avoid human injury or product damage.

Precautions for Power Cables and Accessories

- ⚠ Use proper power source only. Make sure the supply voltage falls within the specified range. Always check whether the Product is DC powered before applying power.
- ⚠ Place the power cable properly at places without extrusion hazards.
- ⚠ Use only approved antenna(s). Non-approved antenna(s) may produce spurious or excessive RF transmitting power which may violate FCC limits.
- ⚠ Cleaning instructions:
 - Power off before cleaning the Product
 - Do not use caustic or aggressive liquids, vapor, or spray
 - Clean with a damp cloth
 - Do not try to clean exposed electronic components unless with a dust collector
- ⚠ Power off and contact Vantron technical support engineer in case of the following faults:
 - The Product is damaged
 - The temperature is excessively high
 - Fault is still not solved after troubleshooting according to this manual
- ⚠ Do not use in combustible and explosive environment:
 - Keep away from combustible and explosive environment
 - Keep away from all energized circuits
 - Unauthorized removal of the enclosure from the device is not allowed
 - Do not change components unless the power cable is unplugged
 - In some cases, the device may still have residual voltage even if the power cable is unplugged. Therefore, it is a must to remove and fully discharge the device before replacement of the components.

CHAPTER 1 HARDWARE DESCRIPTION








1.1 Product Overview


Vantron R105 industrial router offers different options for industrial IoT connectivity, including cellular, Wi-Fi, Ethernet, and virtual private network (VPN) to meet diversified networking requirements. It offers mid- and high-speed CAT 4 cellular networks with major carriers supported. It implements 5 gigabit Ethernet jacks, including one LAN port that offers the PoE option to supply up to 30W of power to client devices. With Wi-Fi IEEE 802.11 b/g/n/ac supported, R105 offers IEEE 802.11ax (Wi-Fi 6) as an option to customers to meet higher communication needs.

R105 industrial router supports multi-channel failover to maintain secure and stable network access. With BlueSphere GWM, a web-based cloud platform for centralized management of mass routers and gateways, you can further configure and manage the router remotely. R105 is very suitable for application in industrial automation, smart home, smart city, etc.

1.2 Unpackaging

The Product has been carefully packed with special attention to quality. However, should you find any component damaged or missing, please contact your sales executive in due time.

Standard accessories		Optional accessories	
	1 x R105 router		1 x 12V DC Power adapter & power cord
	2 x 4G LTE antenna (rubber stick)		1 x DC power connector
	2 x Wi-Fi antenna (rubber stick)		2 x 4G LTE antenna (magnetic sucker)
	1 x DIN rail mounting bracket (attached)	/	/


 Actual accessories might vary slightly from the list above as the customer order might be different from the standard configuration options.

1.3 Specifications

R105			
Communication	Ethernet	5 x RJ45, 10/100/1000Mbps (1 x WAN & 4 x LAN, PoE optional, 30W output)	
	Wi-Fi	2.4GHz & 5GHz, IEEE 802.11 b/g/n/ac, AP & Client Optional: Wi-Fi 6, IEEE 802.11 b/g/n/ac/ax	
	4G LTE	LTE CAT 4, multi-carrier supported	
	WAN protocol	PPP, DHCP	
I/Os	Console	1 x Console for local configuration	
	Serial port	1 x RS485, isolated 1 x RS232, isolated	
	SIM slot	2 x SIM slot	
	Antenna (SMA conn.)	2 x LTE antenna	2 x Wi-Fi antenna
	Grounding	Enclosure & PCB	
	Power in	1 x 3.81mm Phoenix terminal block	
System Control	LED indicator	3 x Cellular signal strength indicator 1 x Power indicator 1 x System indicator	1 x Internet indicator 1 x WLAN indicator
	Button	1 x Pinhole reset button	
Mechanical	Dimensions	150mm x 115mm x 35mm	
	Enclosure	Metal	
	Installation	DIN rail mounting, panel mounting, wall mounting	
	IP rating	IP30	
	Drop test	6 ft. drop test	
	Cooling mode	Fanless	
Power	Input	9-36V DC, over-current protection, reverse polarity protection	
Software	OS	VantronOS	
	Network management	SNMP v2c/v3	
	Networking protocol	IPv4, HTTPS, TCP & UDP, NTP client and server, ARP, TLS	
	VLAN	Supported	
	Device management platform	BlueSphere GWM	
	Link detection	Heartbeat detection, automatic re-connection	
	Device log	Retrievable	
	Network reliability	Multi-channel failover, backup between Ethernet, Wi-Fi, 4G LTE	
	Dual SIM	Dual SIM failover, automatic switch	
	IP application	Ping, Traceroute, DHCP Server/Client, DDNS	
	IP Routing	Static routing, dynamic routing	
	NAT	Supported	
Security	Firewall	Supported (Stateful)	
	Access control	MAC address, IP address	
	Data security	PPTP, L2TP, GRE, IPSec, OpenVPN	
	Wi-Fi security	64/128-bit WEP, TKIP, WPA, WPA2, WPA3, AES, WPS	
Environment Condition	Temperature	Operating: -20°C~+60°C	Storage: -40°C~+70°C
	Humidity	Storage: RH 5%~95% (non-condensing)	
	Certification	FCC, IC, PTCRB, AT & T, Verizon, T-Mobile	

1.4 Definition of Interfaces

1.4.1 Front view



Indicator/Interface	Description
1	Wi-Fi status indicator
2	Network connectivity indicator
3	Power indicator
4	System status indicator
5	4G LTE signal strength indicator
6	Console port for debugging the device (baud rate: 57600)
7	WAN port, mapped as eth0.2 in VantronOS, working in the WAN area by default
8	4 x LAN port, mapped as eth0.1 in VantronOS, working in the LAN area by default

Description of the LED indicators

1. Wi-Fi status indicator

Wi-Fi status	Description
The Wi-Fi module is turned on	The indicator turns solid green
There is Wi-Fi connectivity	The indicator blinks
The Wi-Fi module is turned off	The indicator is off

2. Network connectivity indicator

Network connectivity of the Router	Description
There is no internet access through any of the available connectivity routes	The indicator is off
The router has internet access from any of the routes	The indicator blinks at an interval of 1 second

3. Power indicator

When the Router is powered on, the power indicator will turn solid green.

4. System status indicator

System action	Description
System bootup in process	The indicator is off
System running properly	The indicator blinks at an interval of 1 second
System reboot, upgrade or factory reset	The indicator blinks quickly at an interval of 0.3 seconds

5. 4G LTE signal strength indicator

Signal strength	Description
>67%	The three indicators turn solid green
Between 38% and 67%	The bottom two indicators turn solid green
<38%	The bottom indicator blinks

1.4.2 Left side view



Interface	Description
1	Wi-Fi antenna connector 1
2	Pinhole RESET button
3	Power terminal (9V-36V DC)
4	Secondary 4G LTE antenna connector
5	Primary 4G LTE antenna connector
6	RS232 & RS485 serial connectors
7	Wi-Fi antenna connector 2

Description of the RESET button

1. A short press of the button for 0 ~ 2 seconds will restart the Router.
2. A long press of the button for 3 ~ 6 seconds will factory reset the Router.
3. A long press of the button for 6 ~ 10 seconds will factory reset the Router with all user data cleared.

1.4.3 Right side view




Interface	Description
1	Micro SIM slot 1
2	Micro SIM slot 2
3	Grounding screw

1.4.4 Back view



Interface	Description
1	DIN rail bracket

1.5 Serial Port Description



The terminal block incorporates an RS232 port and an RS485 port with pinout description as follows:

No.	Signal	Device name	Port	Type	Description
1	RX	/dev/ttyS1	COM1	I	RS232 receive signal
2	TX			O	RS232 transmit signal
3	232. GND			NC	RS232 isolated ground
4	485. GND	/dev/ttyS2	COM2	NC	RS485 isolated ground
5	A			I/O	RS485 A signal
6	B			I/O	RS485 B signal

For RS232 port connection: RX-TX, TX-RX, GND-GND

For RS485 port connection: A-A, B-B, GND-GND

Input the following command to open the serial port with a serial port communication program (e.g., microcom):

COM1:

```
~# microcom /dev/ttyS1 -s 115200
```

COM2:


```
~# microcom /dev/ttyS2 -s 115200
```

CHAPTER 2 GETTING STARTED


2.1 Setting up the Router

Before you proceed with configuration of the Router, follow the steps below to finish hardware connection.

1. Hold the Router uprightly;




2. Place the Router on the DIN rail at an angle;
3. Fit one side of the DIN rail to the clip at the top of the DIN rail bracket, behind the triangle fixer;




4. Push the Router down to compress the bracket;


5. Release the Router when there is enough space for the other side of the DIN rail to fit in the downside of the DIN rail bracket;




6. Gently swing the Router to make sure it is fastened on the DIN rail;
7. Insert an activated Micro SIM card into either of the SIM slots with the gold-colored contacts facing up and the clipped side inward;




8. Push the Micro SIM card in to secure it;
9. Install the Wi-Fi antennas (rubber stick) to the WLAN antenna connectors;



10. Install the LTE antennas (rubber stick /magnetic sucker) to the LTE antenna connectors (if only one antenna is shipped, install to the LTE 1 connector);




11. Tighten the rotating heads to secure the antennas in proper position;
12. Connect one end of an Ethernet cable to the WAN port of the Router and the other to a live Ethernet port;




▶ Skip this step if you choose wireless network connection.

13. Connect one end of another Ethernet cable to a LAN port of the Router and the other to a host computer or client device depending on your use;



14. Connect the terminal end of the DC power connector to the power terminal of the Router and the round end to the adapter;



15. Plug the adapter to a DC power outlet that meets the supply voltage requirement (9V to 36V) to turn on the Router ;
16. The power indicator will turn solid green upon power application.


▶ *The antennas might be different from what used for illustration here. Should you have any trouble installing the antennas, please contact the sales executive for solution.*

2.2 Router Login

The Router is designed to allow network connectivity with minimal configuration. That being said, you can configure the network settings and customize the Router from VantronOS interface.


1. Input the LAN port IP address of the Router in your browser to log in the VantronOS web interface (default: <http://172.18.1.1/>).

- Default user: **admin** / Super user: **root**
- Default password: **admin** / Super user password: **rootpassword**



2. For SSH login, use the LAN port IP address (default: <http://172.18.1.1/>).

- Port: **22**
- Account: **root**
- Password: **rootpassword**

 *The web login address coincides with the LAN port IP address of the Router, so you might have to change the login address when you reset the IP address.*

 *SSH login is disabled by default, refer to **SSH Access** included in [3.13.3](#) for more details.*


2.3 Password Change

It is up to you to decide whether you would like to change the login password after logging in VantronOS.

1. Navigate to **System > Administration**;
2. Input the original password for the current user;
3. Input a new password and confirm the password;
4. Save the settings and apply;
5. The system will log out automatically;
6. Log in with the new password.

2.4 Language Change

Currently the system supports simplified Chinese and English. The system language is set to automatically follow your browser language by default. You can change the system language by navigating to **System > System > Language and Style**.



Auto: System language based on the browser language (default)

English: English interface

Simplified Chinese: Simplified Chinese interface

2.5 Interfacing with Vantron Gateway Management Platform

BlueSphere Gateway Management Platform ("GWM") is a cloud-based management portal that empowers organizations to seamlessly provision, monitor, and manage Vantron IoT communication devices, including gateways, routers, and DTUs. By leveraging BlueSphere GWM, organizations can streamline device setup, ensure real-time visibility into device performance, and effortlessly control device configurations. This contributes to enhanced operational efficiency and improved decision-making.

Before you can use the BlueSphere GWM for remote management of Vantron IoT devices, please make sure the following prerequisites are met:



- You have obtained a license for login to the BlueSphere GWM
- The DMP agent is installed on the device for remote management
- The DMP agent is "enabled" (Refer to [3.10.4 DMP Agent](#) for the configuration)
- The serial number of the device is added to the BlueSphere GWM

CHAPTER 3 ROUTER SETUP VIA VANTRONOS

3.1 Introduction to VantronOS

VantronOS is an intelligent operating system developed by the Vantron team, featuring independent system and function development. It is built upon the Linux system and optimized for embedded hardware. The operating system follows a modular design and plug-in expansion approach, utilizing the Linux kernel with a built-in firewall to ensure secure internet connectivity for Vantron IoT communication devices, protecting them from potential attacks.

VantronOS incorporates a user-friendly UI interface based on the MVC framework, providing a simple and efficient setting entry for users. Additionally, it offers seamless interfacing with various cloud management platforms, including the self-developed BlueSphere GWM, as well as popular platforms like Azure, Alibaba Cloud, Huawei Cloud, and RootCloud. This enables users to remotely monitor, operate, and diagnose devices without the need for on-site technical support engineers. VantronOS facilitates the interconnection and interaction between users and the Industrial Internet of Things, enhancing the overall efficiency and convenience of device management.

-  *In the following sections, should you find any features not displayed in the VantronOS interface as an 'admin' user, please log in with the root account.*
-  *Make sure to save all settings and changes before exit to let them take effect.*

3.2 Status

This page provides the overall information of the Router, including stable operation duration, number of devices connected to the Router via wireless or Ethernet connection, default routing, hardware information, traffic statistics, etc.



Description of the numbered areas

1. Firmware version and auto refresh on/off (click to switch the mode)
2. Stable running duration of the Router since network connection
3. Current working status of the Ethernet ports

(LAN2, LAN4, and the WAN port are connected in this case)


4. A collection of the network diagnostic tools (refer to [3.7](#) for details)
5. Instant outbound traffic
6. The model, serial number, and management address of the router in use
7. System log information
8. Kernel log information
9. Number of clients connected to the Router via Wi-Fi

 *You will access Wi-Fi settings upon a click of the number.*


10. Address information of clients connected to the Router via Ethernet

IPv4-Address	MAC-Address
172.18.1.224	16:0b:0e:4c:99:ac
172.18.1.126	ce:76:f9:f2:e7:e8


11. Details of the router connectivity

 *The illustrative image varies with the communication module on the Router.*

12. Default route currently used by the Router
13. Traffic distribution of clients connected to the Router displayed by MAC addresses

 *Clicking on each MAC address in the table at the page bottom will get the detailed traffic information of the clients.*


14. Traffic of application layer protocols

 *HTTPS, HTTP, and QUIC represent the top 3 protocols for data download and upload.
HTTPS, HTTP and DNS represent the top 3 protocols for device connection.*

3.3 Quick Start— Auto Routing

Automatic routing ensures that the Router maintains Internet access when multiple links are available. It features automatic link detection, automatic route switching, and recovery.

The default link detection and data forwarding are prioritized based on the following rule: Ethernet > Wi-Fi > LTE > others.



Description of the numbered areas

1. Enable/Disable route tracking
2. Mode of the automatic routing (refer to the details below)
3. Automatic link detection policy (refer to the details below)
4. Enable/Disable link detection for a specific network interface
In the screenshot above, wan stands for Ethernet connection, cell0 for cellular connection, and wwan0 for Wi-Fi connection.
5. Enable/Disable gateway detection
6. Customized IP address detection (heartbeat or gateway address)
7. Edit the auto routing rule of a specific network interface (refer to the details below)
8. Link status
9. Link detection log and service running log

Mode of the automatic routing

Mode	Description
Static mode (Default)	<ol style="list-style-type: none">1. The user-designated link priority takes precedence;2. If the user does not designate the link priority, the default rule will apply.
Dynamic mode	<ol style="list-style-type: none">1. The default rule governs the entire routing policy;2. The user-designated link priority will be disabled. <p>This is not recommended when special applications are installed on the Router that rely on the designated link priority.</p>

Automatic link detection policy

Policy	Description
Detect customized IP addresses (Default)	<ol style="list-style-type: none">1. You can set IP addresses for a specific network interface. If these IP addresses have packets received and transmitted, the interface is active and set "Online";2. If the Router is located at a place without access to external network, please change the policy to "Detect gateway" or add some IP addresses that the Router can detect.
Detect gateway	<p>This policy is to identify the IP address of the gateway on the current network.</p> <p>You are recommended not to apply this policy for P2P/PPP connection scenarios, in which circumstance, verifying the public network IP address (such as 8.8.8.8) is recommended.</p>

Note:

1. Please choose an appropriate policy based on the device's network position and the network access protocol used by the network interface.
2. If you have configured for both "Detect customized IP addresses" and "Detect gateway", the gateway detection will take precedence.
3. If you have selected "Detect customized IP addresses" but have not provided any IP address, it will automatically switch to gateway detection.
4. Refer to the next page on editing the routing rules for more details.

Clicking on the **Edit** button behind an interface will direct you to the rule editing page as follows.

Advanced Setting

Interface

Interface	wan
Enable/Disable	Enable
Metric	10
Count	3
Timeout	5
Interval	10
Detect Gateway	Disable
Detect Customized IP Addresses	Factory default

Back or Refresh

Save & Apply Save Reset

Description of the numbered areas

1. Enable/Disable the route tracking on this interface
2. Gateway metric (The smaller the number, the higher the priority)
3. The count of total messages sent in case of a detection timeout (3 by default)
4. The timeout for a single tracking (5s by default)
5. Tracking interval, defined as from the completion of one tracking to the initiation of the next tracking (10s by default)
6. Enable/disable gateway detection
7. Select the default IP addresses ('factory default') or customized IP addresses ('custom') for IP detection
8. **Save & Apply** the settings
9. Go back to the automatic routing page

3.4 Virtual Tunnel

A virtual private network (VPN) lets you use the Internet to securely access your network remotely. The Router supports such VPN protocols as PPTP, L2TP, GRE, IPSec, and OpenVPN to ensure data confidentiality and undisturbedness.


You can configure the Router either as an OpenVPN server or an OpenVPN client based on needs.

3.4.1 OpenVPN Server

This page provides virtual private network based on SSL connection and transmission, which features simple and flexible configurations, better security, and no interference.

Follow the steps below to build an OpenVPN server:

1. Synchronize the Router time with the browser (local) time;
2. Enable the server or not after the server is built;
3. Select a protocol (TCP by default);

 *TCP provides an ordered delivery of data from the user to server (and vice versa), whereas UDP is not dedicated to end-to-end communications, nor does it check the readiness of the receiver.*

4. Select a working mode between **tap** and **tun** (tun by default);

▶ **Tap** bridges two ethernet segments at different locations, so use **tap** if you need to connect to remote network (remote desktops, PLCs, controllers, etc.). If you only need network connection, then use **tun**.

5. Set a port that the server is to monitor;
6. Choose the WAN port IP or DDNS or public IP that the server is to monitor;
7. Assign a virtual IP network for the clients;
8. The basic configurations sent to the clients (not applicable to the tap working mode);
9. The extension configurations sent to the clients;
10. Download the configuration file for client connection (not necessary for server setup);
11. **Save & Apply** the settings;
12. Status of the OpenVPN server after the setup.

OpenVPN Server

openvpn server is running---,the pid number: 23162

Advanced Setting allows you to set the authentication method, certificate authentication options, and renew the system certificate.




Run Log displays the details after the server setup.



3.4.2 VPN Client

To connect the Router to a VPN server and use it as a client, navigate to **Virtual Tunnel > VPN Client** for specific settings.



Description of the numbered areas

1. Synchronize your VPN time with the browser (local) time
2. Select a WAN protocol for the virtual line (OPENVPN & PPTP available)
3. Click to switch to the protocol
4. Check or uncheck the box to enable/disable the protocol
-  Only when the protocol is enabled will subsequent options be displayed. The subsequent options correspond to the type of WAN protocol selected.
5. If you select OpenVPN as the WAN protocol, you'll have to continue with the configuration using a .ovpn file
-  If you select PPTP as the WAN protocol, you shall input the PPTP server IP, user name and password as indicated.
6. Select the .ovpn file from the local directory for configuration
7. Upload the file
8. Select to use a certificate or username & password for the authentication
-  The mode will update automatically, leave it as is.

9. Set the MTU
10. Set the gateway metric (between 1 and 255)
 *The smaller the number, the higher the priority.*
11. Disable/Enable heartbeat detection
 *Select **custom** and enter the IP address for heartbeat detection to enable the mechanism.*
12. Enter a custom DNS server
13. **Save & Apply** the settings
14. Status of the VPN client after the setup

VPN Client

dial success IPv4: 10.8.0.1/255.255.255.0 Uptime:0h 7m 4s RX: 0 B TX: 0 B the pid number:16301


3.5 IPsec Connection

3.5.1 Prerequisites

- An R105 industrial router ('G1' for short)
 - A supporting device (gateway/router) that runs on VantronOS and supports IPsec ('G2' for short)
 - Certificates for the router and the supporting device:
1. Assume that the IP addresses of the G1 and G2 are as follows:
G1— LAN IP: 172.18.2.1, WAN IP: 192.168.9.78
G2— LAN IP: 172.18.3.1, WAN IP: 192.168.9.82
 2. Assume the certificates of the two devices are as follows:
G1—
X509 root certificate: rootca.cert
X509 certificate: 78.cert
Private key: 78.priv.key
Public key: 78.pub.key
G2—
X509 root certificate: rootca.cert
X509 certificate: 82.cert
Private key: 82.priv.key
Public key: 82.pub.key

3.5.2 Certificate Setup

- Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > Certificate Management** to upload the certificates (take G1 as an example):



Follow the steps below to upload the certificates.

1. Select the X509 root certificate;
2. Select the X509 certificate;
3. Select the private key;
4. Select the public key;
5. Click **OK** to upload the certificates for G1.

The above screenshot only illustrates how to upload the certificates for G1. Please follow the same way to upload the certificates for G2.

You can use the tool located at the bottom of the page to generate a pair of private and public keys, which, however, can only be used as public key authentication.

The screenshot displays the 'IPSEC Certificate Config' interface. It features two tables for key management and a section for generating new keys.

private key informations

ID	Name	Filesize	subjkey	Action
0	82.pub.key.pem	1675	78:4a:5a:9a:88:2e:13:2c:60:5d:96:ed:e7:35:d5:b8:9e:46:8a:02	Delete
1	82.priv.key.pem	1679	30:7a:34:15:92:a4:b7:20:21:e9:6c:ae:a7:ea:3f:b9:70:a1:e4:82	Delete

public key informations

ID	Name	Filesize	subjkey	Action
0	82.pub.key.pem	451	78:4a:5a:9a:88:2e:13:2c:60:5d:96:ed:e7:35:d5:b8:9e:46:8a:02	Export Delete
1	82.priv.key.pem	451	30:7a:34:15:92:a4:b7:20:21:e9:6c:ae:a7:ea:3f:b9:70:a1:e4:82	Export Delete

IPSEC Certificate Config

X509 RootCA: Choose File rootca.cert

X509 Certificate: Choose File 78.cert

Private Key: Choose File 78.priv.key

Public Key: Choose File 78.pub.key

OK Cancel

Auto generate one pair of private and public key

Filename: test 1

Generate 2

private key informations

ID	Name	Filesize	subjkey	Action
0	test.pem 3	1675	a7:ec:00:f6:d4:75:63:d6:eb:52:af:ab:b1:7e:cd:ae:40:50:32:4d	Delete
1	82.pub.key.pem	1675	78:4a:5a:9a:88:2e:13:2c:60:5d:96:ed:e7:35:d5:b8:9e:46:8a:02	Delete
2	82.priv.key.pem	1679	30:7a:34:15:92:a4:b7:20:21:e9:6c:ae:a7:ea:3f:b9:70:a1:e4:82	Delete

public key informations

ID	Name	Filesize	subjkey	Action
0	test.pem 4	451	a7:ec:00:f6:d4:75:63:d6:eb:52:af:ab:b1:7e:cd:ae:40:50:32:4d	Export Delete
1	82.pub.key.pem	451	78:4a:5a:9a:88:2e:13:2c:60:5d:96:ed:e7:35:d5:b8:9e:46:8a:02	Export Delete
2	82.priv.key.pem	451	30:7a:34:15:92:a4:b7:20:21:e9:6c:ae:a7:ea:3f:b9:70:a1:e4:82	Export Delete

Description of the numbered areas

1. Input a file name for the keys
2. Click **Generate** to generate the keys
3. Newly generated private key
4. Newly generated public key

3.5.3 Secret Setup

This configuration only applies when pre-shared key (PSK) is selected as the secret type.

- Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > Secretes Management** to configure a local secret (take G1 as an example):

The screenshot displays the Vantron web interface for configuring IPSEC secrets. On the left, a sidebar menu includes 'Status', 'Quick Start', 'Virtual Tunnel' (selected), 'OpenVPN Server', 'IPSEC', 'VPN Client', 'Network', and 'Users Manage'. The main panel is titled 'IPSEC Setting' and contains a sub-menu with 'IPSEC Connections', 'Create Connection In Guide', 'IKE policy', 'IPSEC policy', 'Authentication Management', 'Secrets Management' (highlighted), 'Certificate Management', 'Virtual IP Pools', and 'IPSEC Setting'. The 'IPSEC secrets management' section features a table with columns: ID, Enable, Name, Auth, Identify(ID), Secret, and Action. Below the table is the 'IPSEC Secrets Config' form, which includes fields for Name (set to 'local_pwd'), Enable (set to 'Enabled'), Secret Type (set to 'PSK(Pre-Shared Key)'), PSK ID [] (set to '192.168.9.78'), and Secret (set to 'pwdtest'). Numbered callouts 1 through 5 point to these respective fields. At the bottom of the form are 'OK' and 'Cancel' buttons, with a callout 6 pointing to the 'OK' button.

Follow the steps below to set a **local secret**.

1. Assign a name for the secrete;
2. Select **Enabled** from the dropdown list to enable the secret;
3. Select **PSK** as the secret type;
4. Input the PSK ID: 192.168.9.78 (WAN IP of G1);
5. Input a password;
6. Click **OK** to save the secret.

- Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > Secretes Management** to configure a remote secret (take G1 as an example):

The screenshot shows the 'IPSEC Setting' page with the 'Secretes Management' tab selected. On the left, a sidebar lists navigation options: Status, Quick Start, Virtual Tunnel (selected), OpenVPN Server, IPSEC, VPN Client, Network, and Users Manage. The main content area is divided into 'IPSEC Status' and 'IPSEC Setting'. Under 'IPSEC Setting', there's a sub-menu with 'IPSEC Connections', 'Create Connection In Guide', 'IKE policy', 'IPSEC policy', 'Authentication Management', 'Secrets Management' (highlighted), 'Certificate Management', 'Virtual IP Pools', and 'IPSEC Setting'. The 'IPSEC secrets management' section contains a table with one entry (ID 0, Name local_pwd, Auth psk, Identify(ID) 192.168.9.78, Secret pwdtest) and 'Edit' and 'Delete' links. Below this is the 'IPSEC Secrets Config' form with fields: Name (remote_pwd), Enable (Enabled), Secret Type (PSK(Pre-Shared Key)), PSK ID (192.168.9.82), and Secret (testpwd). Numbered callouts 1-6 point to these fields and the OK button.


Follow the steps below to set a **remote secret**.

1. Assign a name for the secrete;
2. Select **Enabled** from the dropdown list to enable the secret;
3. Select **PSK** as the secret type;
4. Input the PSK ID: 192.168.9.82 (WAN IP of G2);
5. Input a password;
6. Click **OK** to save the secret.

IPSEC secrets management						
ID	Enable	Name	Auth	Identify(ID)	Secret	Action
0	<input checked="" type="checkbox"/>	local_pwd	psk	192.168.9.78	pwdtest	Edit Delete
1	<input checked="" type="checkbox"/>	remote_pwd	psk	192.168.9.82	testpwd	Edit Delete

The local secret of G1 acts as the remote secret of G2, and the remote secret of G1 acts as the local secret of G2.


3.5.4 IPSec Connection Setup



Introduction to the above scenarios

- Scenario 1: Host-to-Host, G1 connects with G2 via IPSec, and subnets are not connected
- Scenario 2: Site-to-Site, G1 connects with G2 via IPSec, and subnets are connected
- Scenario 3: Remote access (Server), D connects to G1 via IPSec with access to subnets of G1
- Scenario 4: Remote access (Client), A connects to G2 via IPSec with access to subnets of G2


STEP 1: Enabling IPsec



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > IPSEC Setting**
2. Enable IPsec settings
3. Click **OK** to save the setting


After the settings are loaded, the status of IPsec will change to 'running' as follows.



STEP 2: IKE policy configuration

Configurations for scenarios 1 and 2:


G1 setup



Description of the numbered areas

1. Navigate to **Virtual Tunnel** > **IPSEC** > **IPSEC Setting** > **IKE policy**
2. Assign a name to the policy
3. Select **Enabled** from the dropdown list to enable the policy
4. Input the local address: 192.168.9.78
5. Input the remote address: 192.168.9.82
6. Click **OK** to save the settings

G2 setup




Description of the numbered areas

1. Navigate to **Virtual Tunnel** > **IPSEC** > **IPSEC Setting** > **IKE policy**
2. Assign a name to the policy
3. Select **Enabled** from the dropdown list to enable the policy
4. Input the local address: 192.168.9.82
5. Input the remote address: 192.168.9.78
6. Click **OK** to save the settings

Configurations for scenario 3 (swapping the configurations of G1 and G2 will get you the configurations for scenario 4):


G1 setup



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > IKE policy**
2. Assign a name to the policy (to_82)
3. Select **Enabled** from the dropdown list to enable the policy
4. Input the local address: 192.168.9.78
5. Input the remote address: 192.168.9.82
6. Click **Advanced** to access the advanced settings
7. Click **Virtual IP Pools**
8. Select 'Responder' as the role of G1
9. Double click the available 'to_82' IP to select it
10. Click **OK** to save the settings

G2 setup



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > IKE policy**
2. Assign a name to the policy (to_78)
3. Select **Enabled** from the dropdown list to enable the policy
4. Input the local address: 192.168.9.82
5. Input the remote address: 192.168.9.78
6. Click **Advanced** to access the advanced settings
7. Click **Virtual IP Pools**
8. Select 'Initiator' as the role of G2
9. Input a virtual IP (0.0.0.0)
10. Click **OK** to save the settings

STEP 3: IPSec policy configuration

Configurations for scenario 1:

G1 setup



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > IPsec policy**
2. Assign a name to the policy (to_82)
3. Select **Enabled** from the dropdown list to enable the policy
4. Select **Tunnel** as the transport mode
5. Input the local address: 192.168.9.78
6. Input the remote address: 192.168.9.82
7. Click **OK** to save the settings

G2 setup



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > IPsec policy**
2. Assign a name to the policy (to_78)
3. Select **Enabled** from the dropdown list to enable the policy
4. Select **Tunnel** as the transport mode
5. Input the local address: 192.168.9.82
6. Input the remote address: 192.168.9.78
7. Click **OK** to save the settings

Configurations for scenario 2:

G1 setup



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > IPsec policy**
2. Assign a name to the policy (to_82_site)
3. Select **Enabled** from the dropdown list to enable the policy
4. Select **Tunnel** as the transport mode
5. Input the local address: 172.18.2.1/24 (LAN IP of G1)
6. Input the remote address: 172.18.3.1/24 (LAN IP of G2)
7. Click **OK** to save the settings

G2 setup




Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > IPsec policy**
2. Assign a name to the policy (to_78_site)
3. Select **Enabled** from the dropdown list to enable the policy
4. Select **Tunnel** as the transport mode
5. Input the local address: 172.18.3.1/24 (LAN IP of G2)
6. Input the remote address: 172.18.2.1/24 (LAN IP of G1)
7. Click **OK** to save the settings

Configurations for scenario 3 (swapping the configurations of G1 and G2 will get you the configurations for scenario 4):

Virtual IP setup of G1



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > Virtual IP Pools**
2. Assign a name to the policy (to_82)
3. Select **Enabled** from the dropdown list to enable the policy
4. Input a virtual address: 10.10.7.0/24
5. Click **OK** to save the settings


IPSec policy of G1



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > IPSec policy**
2. Assign a name to the policy (to_82_server)
3. Select **Enabled** from the dropdown list to enable the policy
4. Select **Tunnel** as the transport mode
5. Input the local address: 10.10.7.0/24
6. Click **OK** to save the settings


Navigate to **System > Terminal > Settings** to enable the terminal.



Log in with root account (default password: rootpassword), and input the following command to add the IP to G1.

```
ip address add 10.10.7.2/24 dev eth0
```

IPSec policy of G2



Description of the numbered areas


1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > IPSEC policy**
2. Assign a name to the policy (to_78_client)
3. Select **Enabled** from the dropdown list to enable the policy
4. Select **Tunnel** as the transport mode
5. Input the remote address: 10.10.7.0/24
6. Click **OK** to save the settings

STEP 4: Authentication management

Three ways are available for the authentication: certificate, PSK, and public key.

Certificate authentication


Configurations of G1 for local authentication



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > Authentication Management**
2. Assign a name for the certificate (local_cert)
3. The certificate is **Enabled** by default
4. **Certificate** is the default authentication method
5. Double click the available '78.cert' certificate to select it
6. Click **OK** to save the settings


Configurations of G1 for remote authentication



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > Authentication Management**
2. Assign a name for the certificate (remote_cert)
3. The certificate is **Enabled** by default
4. **Certificate** is the default authentication method
5. Double click the available '78.cert' certificate to select it
6. Click **OK** to save the settings


Configurations of G2 for local authentication



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > Authentication Management**
2. Assign a name for the certificate (local_cert)
3. The certificate is **Enabled** by default
4. **Certificate** is the default authentication method
5. Double click the available '82.cert' certificate to select it
6. Click **OK** to save the settings

Configurations of G2 for remote authentication



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > Authentication Management**
2. Assign a name for the certificate (remote_cert)
3. The certificate is **Enabled** by default
4. **Certificate** is the default authentication method
5. Double click the available '82.cert' certificate to select it
6. Click **OK** to save the settings

PSK authentication

Configurations of G1 for local authentication


Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > Authentication Management**
2. Assign a name for the certificate (local_cert)
3. The certificate is **Enabled** by default
4. Input the ID same as that set in **Secret Management** (192.168.9.78)

IPSEC secrets management						
ID	Enable	Name	Auth	Identify(ID)	Secret	Action
0	<input checked="" type="checkbox"/>	local_pwd	psk	192.168.9.78	pwdtest	Edit Delete
1	<input checked="" type="checkbox"/>	remote_pwd	psk	192.168.9.82	testpwd	Edit Delete

5. Select **PSK (Pre-shared key)** from the drop-down list as the authentication method
6. Click **OK** to save the settings

Configurations of G1 for remote authentication




Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > Authentication Management**
2. Assign a name for the certificate (remote_cert)
3. The certificate is **Enabled** by default
4. Input the ID same as that set in **Secret Management** (192.168.9.82)

IPSEC secrets management						
ID	Enable	Name	Auth	Identify(ID)	Secret	Action
0	<input checked="" type="checkbox"/>	local_pwd	psk	192.168.9.78	pwdtest	Edit Delete
1	<input checked="" type="checkbox"/>	remote_pwd	psk	192.168.9.82	testpwd	Edit Delete

5. Select **PSK (Pre-shared key)** from the drop-down list as the authentication method
6. Click **OK** to save the settings


Configurations of G2 for local authentication



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > Authentication Management**
2. Assign a name for the certificate (local_cert)
3. The certificate is **Enabled** by default
4. Input the ID same as that set in **Secret Management** (192.168.9.82)
5. Select **PSK (Pre-shared key)** from the drop-down list as the authentication method
6. Click **OK** to save the settings

Configurations of G2 for remote authentication




Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > Authentication Management**
2. Assign a name for the certificate (remote_cert)
3. The certificate is **Enabled** by default
4. Input the ID same as that set in **Secret Management** (192.168.9.78)
5. Select **PSK (Pre-shared key)** from the drop-down list as the authentication method
6. Click **OK** to save the settings

Public key authentication

This authentication requires to upload the public key of G1 (78.pub.key) to G2 and upload the public key of G2 (82.pub.key) to G1.


Configurations of G1 for local authentication



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > Authentication Management**
2. Assign a name for the certificate (local_cert)
3. The certificate is **Enabled** by default
4. Select **Public key** from the drop-down list as the authentication method
5. Double click to select '78.pub.key'
6. Click **OK** to save the settings


Configurations of G1 for remote authentication



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > Authentication Management**
2. Assign a name for the certificate (remote_cert)
3. The certificate is **Enabled** by default
4. Select **Public key** from the drop-down list as the authentication method
5. Double click to select '82.pub.key'
6. Click **OK** to save the settings


Configurations of G2 for local authentication



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > Authentication Management**
2. Assign a name for the certificate (local_cert)
3. The certificate is **Enabled** by default
4. Select **Public key** from the drop-down list as the authentication method
5. Double click to select '82.pub.key'
6. Click **OK** to save the settings

Configurations of G2 for remote authentication



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > Authentication Management**
2. Assign a name for the certificate (remote_cert)
3. The certificate is **Enabled** by default
4. Select **Public key** from the drop-down list as the authentication method
5. Double click to select '78.pub.key'
6. Click **OK** to save the settings

STEP 5: Configurations for IPSec connection

G1 setup



Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > IPSEC Connection**
2. Assign a name for the connection (to_82)
3. The certificate is **Enabled** by default
4. Select a previously created IKE policy ('to_82' in this case) from the drop-down list
5. Double click a previously created local authentication policy ('local_cert' in this case) to select the policy
6. Double click a previously created remote authentication policy ('remote_cert' in this case) to select the policy
7. Double click a previously created IPsec policy ('to_82' in this case) to select the policy
8. Click **OK** to save the settings

G2 setup




Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Setting > IPSEC Connection**
2. Assign a name for the connection (to_78)
3. The certificate is **Enabled** by default
4. Select a previously created IKE policy ('to_78' in this case) from the drop-down list
5. Double click a previously created local authentication policy ('local_cert' in this case) to select the policy
6. Double click a previously created remote authentication policy ('remote_cert' in this case) to select the policy
7. Double click a previously created IPsec policy ('to_78' in this case) to select the policy
8. Click **OK** to save the settings

STEP 6: Reloading the IPsec program

Click the radio button before **Reload** and then **OK** to reload the program.



STEP 7: IPsec connection

IPSEC Status

IPSEC Setting

IPSEC Status

[connection list](#) 1

connection details

IPSEC policy status

certificate list

virtual ip pools

IPSEC configurations

IPSEC connection lists informations

ID	IKE Name	local address	remote address	Version	Action
0	to_82	192.168.9.78	192.168.9.82	IKEv1/2	Up Down
	ID IPSEC tunnel	local ts	remote ts	mode	
1	to_82	172.18.2.0/24	172.18.3.0/24	TUNNEL	2 Up Down

Description of the numbered areas

1. Navigate to **Virtual Tunnel > IPSEC > IPSEC Status> Connection list**
2. Select the connection setting and click **Up**

When the connection is added to **IPSEC IKE SAS**, the connection is established successfully.

IPSEC Status

IPSEC Setting

IPSEC Status

[connection list](#)

connection details

IPSEC policy status

certificate list

virtual ip pools

IPSEC configurations

IPSEC logs

IPSEC connection lists informations

ID	IKE Name	local address	remote address	Version	Action
0	to_82	192.168.9.78	192.168.9.82	IKEv1/2	Up Down
	ID IPSEC tunnel	local ts	remote ts	mode	
1	to_82	172.18.2.0/24	172.18.3.0/24	TUNNEL	Up Down

IPSEC IKE sas

ID	IKE Name	local address	remote address	Version	Action
1	to_82	192.168.9.78	192.168.9.82	IKEv2	Down
	IPSEC tunnel	local ts	remote ts	mode	
	to_82-13	172.18.2.0/24	172.18.3.0/24	TUNNEL	Down

3.6 Network

Users can change the settings related to the available network interfaces in the **Network** page.


3.6.1 Interfaces

All the network interfaces currently available and configurable are displayed under **Network > Interfaces**.



Take the LAN port for example, the numbered areas are as follows:

1. Interface overview
2. Interface traffic details
3. Restart the interface manually
4. Edit the interface settings
5. Delete the interface (available only when you log in as a root user)
6. Instantaneous traffic of the interface
7. Add a new interface (available only when you log in as a root user)

 The interfaces may differ from what is shown above as certain interfaces are related to your prior settings and the communication modules available on the device.

The following section illustrates on how to edit the LAN port and WAN port settings of the Router.

3.6.1.1 LAN

- **Common Configurations**

Clicking on the **Edit** button behind the **LAN** port will allow you to access the configurations of the LAN port, and **General Setup** is displayed by default.

Interfaces - LAN

On this page you can configure the network interfaces. You can bridge several interfaces by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also use VLAN notation INTERFACE.VLANNR (e.g.: eth0.1).

Common Configuration

General Setup | Advanced Settings

Status ①

Device: br-lan
Uptime: 24h 4m 10s
MAC: 76:D1:B8:91:17:22
RX: 164.29 MB (362113 Pkts.)
TX: 1.03 GB (1086694 Pkts.)
IPv4: 172.18.1.1

Protocol: Static address

IPv4 address ②: 172.18.1.1

IPv4 netmask ③: 255.255.255.0

Description of the numbered areas

1. Status of the interface
2. The IP address of the LAN port
3. The LAN port subnet mask

In the **Advanced Settings** next to the general setup:

Interfaces - LAN

On this page you can configure the network interfaces. You can bridge several interfaces by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also use VLAN notation INTERFACE.VLANNR (e.g.: eth0.1).

Common Configuration

General Setup | **Advanced Settings** | Physical Settings

Override MAC address ①: 18:9B:A5:16:14:13

Override MTU ②: 1500

Use gateway metric ③: 0

Description of the numbered areas

1. MAC address cloning
2. Set the MTU (keep the default setting)
3. Set a gateway metric (keep the default setting)

 *Be sure to save the settings before you exit the page.*

There is a **Physical Settings** tab next to **Advanced settings** when you log in with the root account, allowing you to configure the LAN port for network bridge.

Interfaces - LAN

On this page you can configure the network interfaces. You can bridge several interfaces by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also use VLAN notation INTERFACE.VLANNR (e.g.: eth0.1).

Common Configuration

General Setup Advanced Settings **Physical Settings**

Bridge interfaces 1 ☒ creates a bridge over specified interface(s)

Enable STP 2 ☐ Enables the Spanning Tree Protocol on this bridge

Interface 3

- ☐ Ethernet Adapter: "erspan0"
- ☐ Ethernet Switch: "eth0"
- ☒ Switch VLAN: "eth0.1" ([lan](#))
- ☒ Switch VLAN: "eth0.2" ([wan](#))
- ☒ Wireless Network: Master "Vantron-237CA6" ([lan](#))
- ☐ Custom Interface:


Description of the numbered areas

1. Enable the interface for network bridge
2. Enable STP protocol
3. Select the interfaces for bridge connection

 *Be sure to save the settings before you exit the page.*


- **DHCP server**

In the **General Setup** page of **DHCP Server**, DHCP could be set up with more details:




Description of the numbered areas

1. Disable the DHCP service

 *If disabled, the DHCP service will not be available to the client devices connected to the LAN port of the Router.*


2. DHCP start address
3. Maximum number of leased addresses (up to 150)
4. Expiry time of leased addresses (min. 2m)

Advanced Settings of DHCP Server:




Description of the numbered areas

1. Enable allocation of DHCP addresses for client devices
2. Force enablement of DHCP service (to bypass other servers)
3. Override the netmask sent to clients

 *Normally it is based on the subnet that is served.*

4. Add different DNS servers for client devices

 *Be sure to save the settings before you exit the page. Clicking on **Back or Refresh** will get you back to the general information of the network interface.*

3.6.1.2 WAN

- **General DHCP settings**

Clicking on the **Edit** button behind the **WAN** port will allow you to access the configurations of the WAN port, and **General Setup** is displayed by default.

Interfaces - WAN

On this page you can configure the network interfaces. You can bridge several interfaces by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also use VLAN notation INTERFACE.VLANID (e.g.: eth0.1).

Common Configuration

General Setup | Advanced Settings

Status	①	<div>Device: eth0.2 Uptime: 22h 5m 9s MAC: 8E:D9:97:00:00:02 RX: 929.56 MB (1193522 Pkts.) TX: 135.71 MB (645207 Pkts.) IPv4: 192.168.1.100</div>
Protocol	②	DHCP client
Hostname to send when requesting DHCP	③	VantronOS-B4A7

Description of the numbered areas

1. Status of the WAN port
2. Select a WAN protocol (DHCP client by default)
3. Input a hostname of the Router for requesting DHCP

 *Be sure to save the settings before you exit the page.*

- **Advanced DHCP settings**

If you have selected DHCP client protocol, advanced settings are available after you have finished the setup as mention above.

Interfaces - WAN

On this page you can configure the network interfaces. You can bridge several interfaces by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also use VLAN notation INTERFACE.VLANID (e.g., eth0.1).

Common Configuration

General Setup **Advanced Settings** Physical Settings Firewall Settings

Bring up on boot 1 ☒

Force link 2 ☐
Set interface properties regardless of the link carrier (If set, carrier sense events do not invoke hotplug handlers)

Use default gateway 3 ☒
If unchecked, no default route is configured

Use DNS servers advertised by peer 4 ☒
If unchecked, the advertised DNS server addresses are ignored

Use gateway metric 5

Override MAC address 6

Override MTU 7

[Back or Refresh](#) [Save & Apply](#) [Save](#) [Reset](#)

Description of the numbered areas

1. Check the box to bring up the port upon device boot
2. Force link (once the box is checked, hotplug handlers will not be invoked after a link change)
3. Enable **Use default gateway**
4. Enable **Use DNS server advertised by peer**
5. Set a gateway metric
6. MAC address cloning
7. Set the MTU

If this option is disabled, you will need to define a DNS server.

Be sure to save the settings before you exit the page.

- **General Static protocol settings**

To activate static address protocol, select **Static address** from the protocol drop-down list under **General Setup** of the WAN port and click **Switch protocol**.

Interfaces - WAN

On this page you can configure the network interfaces. You can bridge several interfaces by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also use VLAN notation INTERFACE.VLANID (e.g.: eth0.1).

Common Configuration

General Setup

Status

Device: eth0.2
Uptime: 0h 1m 31s
MAC: 18-9b-a5-16-14-13
RX: 224.80 KB (2275 Pkts.)
TX: 2.87 KB (44 Pkts.)
IPv4: 192.168.19.54

Protocol: Static address

Really switch protocol? **Switch protocol**

Upon a click of **Switch protocol**, you'll need to input the IPv4 address, subnet mask, IPv4 gateway, and the IPv4 broadcast.

Interfaces - WAN

On this page you can configure the network interfaces. You can bridge several interfaces by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also use VLAN notation INTERFACE.VLANID (e.g.: eth0.1).

Common Configuration

General Setup Advanced Settings Physical Settings Firewall Settings

Status

Device: eth0.2
Uptime: 0h 50m 2s
MAC: 18-9b-a5-16-14-14
RX: 5.92 MB (31584 Pkts.)
TX: 1.75 MB (9918 Pkts.)
IPv4: 192.168.19.225

1 Protocol: Static address

2 IPv4 address: 192.168.19.54

3 IPv4 netmask: 255.255.255.0

4 IPv4 gateway: 192.168.19.222

IPv4 broadcast:

5 Use custom DNS servers: 192.168.19.28

DNS Rebinding

6 Rebind protection: ☐ Refused to parse private address packets

DHCP Server

General Setup





7 Ignore interface: ☒ Disable DHCP for this interface.

Back or Refresh Save & Apply Save Reset

Description of the numbered areas


1. Current protocol
2. Input an IPv4 address
3. Input an IPv4 netmask
4. Input the IPv4 gateway
5. Set a custom DNS server (can be provided by the carrier or self-defined)
6. DNS re-binding protection (if enabled, parsing of private IP data will be refused)
7. Disable DHCP service (keep the default settings)

8. Save & apply the settings

-  Leave the field as is if not applicable.
-  When static address protocol is selected, DHCP server will be automatically disabled.
-  The advanced settings are basically same as those for DHCP protocol.
-  Be sure to save the settings before you exit the page.

Other available WAN protocols include PPPoE, GRE tunnel over IPv4, and relay bridge. The settings are dependent on the specific protocols. Clicking on **Back** or **Refresh** allows you to return to interface settings.

There is a **Physical Settings** tab next to **Advanced settings** when you log in with the root account, allowing you to configure the WAN port for network bridge.



Interfaces - WAN

On this page you can configure the network interfaces. You can bridge several interfaces by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also use `INTERFACE.VLANID` notation (e.g., eth0.1).

Common Configuration

General Setup | Advanced Settings | **Physical Settings** | Firewall Settings

Bridge interfaces 1 ☒ creates a bridge over specified interface(s)


Interface

- ☐ Ethernet Adapter: "4g-cel0" (cel0)
- ☐ Ethernet Adapter: "erpan0"
- ☐ Ethernet Switch: "eth0"
- ☐ Switch VLAN: "eth0.1" (lan)
- ☒ Switch VLAN: "eth0.2" (wan) 2
- ☐ Ethernet Adapter: "tap0" (vnc0)
- ☐ Ethernet Adapter: "usb0" (VPN)
- ☐ Wireless Network: Client "vantron_test5_5G" (vwan0)
- ☐ Custom Interface:

Description of the numbered areas

1. Enable the interface for network bridge
2. Select the interfaces for bridge connection

There is a **Firewall Settings** tab next to the **Physical settings** tab when you log in with the root account, allowing you to create or designate a firewall zone.



Interfaces - WAN

On this page you can configure the network interfaces. You can bridge several interfaces by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also use `INTERFACE.VLANID` notation (e.g., eth0.1).

Common Configuration

General Setup | Advanced Settings | Physical Settings | **Firewall Settings**

Create / Assign firewall zone

- ☐ lan: lan
- ☐ vpn: (empty)
- ☒ wan: vnc0, vwan0, cel0, wan
- ☐ unspecified-or-create:

Choose the firewall zone you want to assign to this interface. Select unspecified to remove the interface from the associated zone or fill out the create field to define a new zone and attach the interface to it.

When 'unspecify or create' is selected, you can remove the interface from the associated firewall zone or create a new zone.


3.6.2 Wireless (WIFI)

You can switch between AP and client modes for wireless connection.

3.6.2.1 Wi-Fi – AP Mode (General settings)

The screenshot shows the 'Wireless(WiFi)' settings page. The 'General Setting' tab is active. The 'Status' section displays: Mode: Master | SSID: Vantron-2B8892 | BSSID: 0C:CF:89:2B:88:92 | Encryption: mixed WPA/WPA2 PSK (CCMP) | Channel: 1 (2.412 GHz) | Tx Power: 20 dBm | Signal: -37 dBm | Noise: -95 dBm | Bitrate: 300.0 Mbit/s | Country: US. The 'WiFi mode' is set to 'AP' with a 'Switch Mode' button. The 'SSID' field (1) contains 'Vantron-2B8892'. The 'Channel' field (2) is set to '1(2412MHz)'. The 'Encryption' field (3) is set to 'WPA-PSK/WPA2-PSK Mixed Mode'. The 'Cipher' field (4) is set to 'Force CCMP (AES)'. The 'Key' field (5) contains a masked password. The 'Associated Stations' table (6) shows one device: Network: (Master 'Vantron-2B8892'), MAC-Address: D6-A2-A0-00, Host: 172.1, Signal / Noise: -37 / -95 dBm, RX Rate / TX Rate: 65.0 Mbit/s, 00 MHz. The page has a 'Back or Refresh' button and 'Save & Apply', 'Save', and 'Reset' buttons.

Description of the numbered areas

1. Set an SSID for the Router
 *The ID name shall not contain special characters including \$, `, \.*
2. Select a Wi-Fi channel
3. Select an encryption method (the following options vary with the encryption method)
4. Select an encryption algorithm
5. Assign a Wi-Fi password (no less than 8 characters)
6. List of currently connected devices

 *Be sure to save the settings before you exit the page.*

3.6.2.2 Wi-Fi – AP Mode (Advanced setting)

Wireless(WiFi)

WiFi Settings

General Setting Advanced Setting

Enable/Disable WiFi ① Disable WiFi

WiFi Frequency ② 2.4G Switch Frequency ③

Network

☐ VPN

☐ cell0

☒ lan ④

☐ vpncli

☐ wan

☐ create:

Choose the network(s) you want to attach to this wireless interface or fill out the create field to define a new network.

Associated Stations

Network	MAC-Address	Host	Signal / Noise
No information available			

Description of the numbered areas


1. Turn on/off Wi-Fi
2. Select a Wi-Fi frequency (determined by hardware)
3. Click to switch the frequency
4. The network interfaces to which Wi-Fi belongs


▶ As modification of field 2 will have impact on the Wi-Fi signal, the web interface will return to the general settings page upon a click of the switch button.

▶ Be sure to save the settings before you exit the page.

3.6.2.3 Wi-Fi – Client Mode

When the Router is set as a client on a wireless network, the page below allows you to make changes to the network settings.

 A `wwan0` port will be added (as shown in the **Interface** page) when the Wi-Fi client mode is enabled.




Description of the numbered areas

1. Switch to **Client mode**
2. Select DHCP protocol to automatically get an IP or Static protocol to specify an IP for the Router
3. Select a wireless network for internet access
4. Select the MAC address of the access point or leave it to 'Auto' if not sure
5. Input the password of the Wi-Fi
6. Click **Scan WIFI** to refresh the Wi-Fi list if the target SSID is not identified

 Be sure to save the settings before you exit the page.

When the Router is successfully connected as a client, there will be the network information next to **Scan WIFI** button.



3.6.2.4 Wi-Fi – AP + Client Mode

This mode enables you to use the Router as an AP to allow client devices to join after it connects a Wi-Fi AP as a client.

Wireless(WiFi)

WiFi Settings

General Setting | Advanced Setting

Status: SSID: ? | Mode: undefined
0% Wireless is disabled or not associated

WIFI mode: AP+Client **Switch Mode** ①

SSID: Vantron-747B3E ②

Channel: 1(2412MHz) ③ **Wi-Fi AP settings**

Encryption: WPA-PSK/WPA2-PSK Mixed Mode ④

Cipher: Force CCMP (AES) ⑤

Key: ***** ⑥

Wifi Client Setting

Select SSID ⑦: 62% ; vantron_test8_5G

Mac/Bssid ⑧: Auto

Key ⑨: **Wi-Fi client settings**

Scan WIFI No connection

Associated Stations

Network	MAC-Address	Host	Signal / Noise
No information available			

Description of the numbered areas

1. Switch to **AP + Client mode**
2. Set an SSID for the Router
3. Select a Wi-Fi channel
4. Select an encryption method (the following options vary with the encryption method)
5. Select an encryption algorithm
6. Assign a Wi-Fi password (no less than 8 characters)
7. Select a wireless network for internet access
8. Select the MAC address of the access point or leave it to 'Auto' if not sure
9. Input the password of the Wi-Fi

Click **Scan WIFI** to refresh the Wi-Fi list if the target SSID is not identified.

Be sure to save the settings before you exit the page.

Status of the connectivity is as follows when the settings take effect.

Wifi Client Setting

Select SSID: 62% ; vantron_test8_5G

Mac/Bssid: Auto

Key: 12345678

Scan WIFI Connected: 0h 0m 57s
IPAddr: 192.168.28.108

Associated Stations

Network	MAC-Address	Host	Signal / Noise
Client "vantron_test8_5G" (wlan0)	68:77:24:38:4C:A8	?	-67 / -92 dBm
Master "Vantron-747B3E" (wlan1)	CE:76:F9:F2:E7:E8	?	-37 / -92 dBm

3.6.3 4G/LTE

Before you configure for 4G/LTE, be sure to install the activated SIM card and the LET antennas following the steps set out in [2.1](#).

Confirm with your sales executive whether the 4G module is AT&T or Verizon pre-certified. If so, when you apply for SIM cards from the carriers,

- provide Verizon with the pre-certified module name **VT-MOB-CELL-mPCle**.
- provide AT&T with the pre-certified module name **VT-MOB-MPCIE-4G**.

After installation, the 4G signal indicators on the Router will light up to indicate the signal strength. Navigate to **Network > 4G/LTE** for more settings.

4G/LTE

SIM Card: Ready Sig: 31(100%) GET IP: 10.147.122.79 IMEI: 869218068976040 ①

SIM1 Card Setting SIM2 Card Setting Advanced Setting Run log 4G traffic

Enable/Disable ②	enable ③
CID Value	1 ④ <small>CID, default: 1</small>
PDP Type	IPv4 Only ⑤ <small>PDP Type: ALL or IPv4_Only or IPv6_Only</small>
APN ⑥	cmnet ⑥
Dial number	*99# ⑦
PAP/CHAP username	your_username ⑧
PAP/CHAP password	***** ⑨

Network Status


Device: 4g-cell0
Uptime: 0h 2m 17s
RX: 304 B (7 Pkts.)
TX: 328 B (8 Pkts.)
IPv4: 10.147.122.79


⑩


Register Status:	Register Home
Register Type:	LTE
Register Network:	CHINA MOBILE(46000)
Modem Firmware:	EC200ACNDAR01A07M16
Device node:	Quactel EC200A ⑪
SIM is using:	sim1
SIM1 Card State:	Inserted
SIM1 Card IMSI:	460008001191840
SIM1 Card ICCID:	89860061221602B41840
SIM2 Card State:	Not Insert
SIM2 Card IMSI:	
SIM2 Card ICCID:	

Description of the numbered areas


1. Connection status information (including SIM card status, signal strength, IP, and IMEI)
2. Set up SIM card 1/2
3. Enable/Disable the SIM card
4. Input the CID value
5. Select a PDP type
6. Input the APN provided by the carrier
7. Input ***99***1#** for SIM cards from AT&T and ***99***3#** for SIM cards from Verizon
8. Enter the username provided by the carrier for PAP/CHAP authentication
9. Enter the password provided by the carrier for PAP/CHAP authentication
10. Current network interface status
11. Detailed information of the SIM cards

 *Leave the field as is if not applicable or if you are not sure.*

 *PAP/CHAP username and password are to be specified only if your carrier has setup APN with user name and password.*

 *If you have inserted a SIM card into SIM slot 2, you can click the **SIM2 Card Setting** tab for more settings.*

In the **Advanced Setting** page, you can further configure the cellular network.




Description of the numbered areas


1. Click to restart the 4G module
2. Time interval for automatic restart of the 4G module when it is offline
3. Time interval for auto refresh of the cellular information

 *Be sure to save the settings before you exit the page.*

The **Run Log** tab next to the **Advanced Setting** tab displays the last 50 log entries of the module.



Under the **4G traffic** tab, traffic information measured in real time or on the monthly and daily basis is available. You can also set the interval for submitting the temporary in-memory database to the persistent database directory.



Description of the numbered areas

1. Real-time traffic
2. Data used in the current month
3. Data used in the day
4. Time interval for submitting the temporary database to the persistent database

3.6.4 Static Routes

This is an advanced function allowing you to specify interface rules for route access.

Example:

Requirement: When the Router has both 4G and WAN network interfaces, the internal network (192.168.0.0 - 192.168.255.254) is accessed via the WAN port by the internal server. Other data access is realized via the 4G interface.

Click **Add** to set a new static route.

Routes

Routes specify over which interface and gateway a certain host or network can be reached.

Static IPv4 Routes

Interface (1)	Target Host, IP or Network (2)	IPv4-Netmask (3) if target is a network	IPv4-Gateway (4)	Metric (5)	MTU (6)	Route type (7)	
wan	192.168.0.0/16	255.255.255.255	192.168.9.222	0	1500	unicast	Delete

Add

Description of the numbered areas

1. Select an interface to configure the route
2. Input the IP address of the host
3. Input the subnet mask (255.255.255.255 by default)
4. Input the address of IPv4 gateway
5. Gateway metric (The smaller the number, the higher the priority)
6. Set the MTU
7. Select a route type (refer to the details next page)

 Be sure to save the settings before you exit the page.

Description of the route type:

Type	Description
Unicast	The route entry describes real paths to the destinations covered by the route prefix.
Local	The destinations are assigned to this host. The packets are looped back and delivered locally.
Broadcast	The destinations are broadcast addresses. The packets are sent as link broadcasts.
Multicast	IP datagrams are sent to a group of interested receivers in a single transmission. It is not present in normal routing tables.
Unreachable	The destinations are unreachable. Packets are discarded and the ICMP message of host unreachable is generated. The local senders will receive an EHOSTUNREACH error.
Prohibit	The destinations are unreachable. Packets are discarded and the ICMP message of communication administratively prohibited is generated. The local senders will receive an EACCES error.
Blackhole	The destinations are unreachable. Packets are discarded silently. The local senders will receive an EINVAL error.
Anycast	The destinations are any cast addresses assigned to this host. They are mainly equivalent to local with one difference that such addresses are invalid when used as the source address of any packet.

3.6.5 Firewall

- **Black List and White List**

The black and white list feature allows you to enable/disable the forwarding of specific addresses.

White list policy: All addresses but those added to the **Access Control Rules** have the access

Black list policy: All addresses but those released to the **Access Control Rules** are blocked

Scenario 1: To block the internet access of 172.18.4.199

Black And White List | Port Forwards | Custom Rules

Firewall - Black And White List

Disable or allow forwarding of certain addresses by setting a black and white list.

General Settings

Strategy Type: WhiteListStrategy (1) Switch Strategy

Access Control Rules

Name	Protocol	Source MAC address	Source IP	Source Port	Dest IP	Dest Port	Action	Enable/Disable
This section contains no values yet								

New Access Control Rules

Name	Protocol	Source MAC address	Source IP	Dest IP	Action
New Access Control Rules	IP (2)		172.18.4.199 (3)		drop (4)

Add (5)

Description of the numbered areas

1. Select the white list strategy and click the button behind to switch to the strategy
2. Select the IP protocol
3. Input the source IP
4. Select 'drop' as the action for the target address
5. Click **Add** to add the address to the access control list

Be sure to save the settings before you exit the page.

Scenario 2: To block the TCP communication between 172.18.4.199 and the external network via port 80

Firewall - Black And White List

Disable or allow forwarding of certain addresses by setting a black and white list.

General Settings

Strategy Type: 1 WhiteListStrategy Switch Strategy

Access Control Rules

Name	Protocol	Source MAC address	Source IP	Source Port	Dest IP	Dest Port	Action	Enable/Disable
This section contains no values yet								

New Access Control Rules

Name	Protocol	Source MAC address	Source IP	Source Port	Dest IP	Dest Port	Action
New Access Control Rule	TCP 2		172.18.4.199 3			80 4	drop 5

Add 6

Description of the numbered areas

1. Select the white list strategy and click the button behind to switch to the strategy
2. Select the TCP protocol
3. Input the source IP
4. Input the destination port
5. Select 'drop' as the action for the target IP and port
6. Click **Add** to add the IP and port to the access control list

 *Be sure to save the settings before you exit the page.*

Scenario 3: To release 172.18.4.199 for internet access

Black And White List | Port Forwards | Custom Rules

Firewall - Black And White List

Disable or allow forwarding of certain addresses by setting a black and white list.

General Settings

Strategy Type (1) BlackListStrategy **Switch Strategy**

Access Control Rules

Name	Protocol	Source MAC address	Source IP	Source Port	Dest IP	Dest Port	Action	Enable/Disable
This section contains no values yet								

New Access Control Rules

Name	Protocol	Source MAC address	Source IP	Dest IP	Action
New Access Control Rules	IP (2)		172.18.4.199 (3)		accept (4)

Add (5)

Description of the numbered areas

1. Select the black list strategy and click the button behind to switch to the strategy
2. Select the IP protocol
3. Input the source IP
4. Select 'accept' as the action for the target IP
5. Click **Add** to release the IP from the access control list

 *Be sure to save the settings before you exit the page.*

Scenario 4: To allow the TCP communication between 172.18.4.199 and the external network via port 80

Black And White List | Port Forwards | Custom Rules

Firewall - Black And White List

Disable or allow forwarding of certain addresses by setting a black and white list.

General Settings

Strategy Type: BlackListStrategy Switch Strategy

Access Control Rules

Name	Protocol	Source MAC address	Source IP	Source Port	Dest IP	Dest Port	Action	Enable/Disable
This section contains no values yet								

New Access Control Rules

Name	Protocol	Source MAC address	Source IP	Source Port	Dest IP	Dest Port	Action
New Access Control Rule	TCP		172.18.4.199			80	accept

Add

Description of the numbered areas

1. Select the black list strategy and click the button behind to switch to the strategy
2. Select the TCP protocol
3. Input the source IP
4. Input the destination port
5. Select 'accept' as the action for the target IP and port
6. Click **Add** to release the IP and port from the access control list

Be sure to save the settings before you exit the page.

- **Port Forwards**

The forwarding controls the traffic between zones and may enable MSS clamping for specific directions. Only one direction is covered by a forwarding rule. To allow bidirectional traffic flows between two zones, two forwarding setups are required with the dest ports reversed.

Example of port forwarding (To forward port 3222 of the WAN port to port 22 of the LAN host 172.18.1.174):

General Settings | **Port Forwards** | Filter Rules | Custom Rules

Firewall - Port Forwards

Port forwarding allows remote computers on the Internet to connect to a specific computer or service within the private LAN.

Port Forwards

Name	Match	Forward to	Enable				
3222to22	IPv4-tcp, udp From any host in wan Via any router IP at port 3222	IP 172.18.1.1, port 3222 in lan	<input checked="" type="checkbox"/>	Up	Down	Edit	Delete

New port forward

Name	Protocol	External zone	External port	Internal zone	Internal IP address	Internal port	
3222to22	TCP+UDP	wan	3222	lan	172.18.1.174 (WM-20210305RYJ.la)	22	Add

Description of the numbered areas

1. Rule name
2. Protocol (TCP/UDP/TCP + UDP are supported)
3. External zone: WAN
4. External port: 3222
5. Internal zone: LAN
6. LAN host: 172.18.1.174
7. Port number of the target host in the internal zone: 22
8. Add the rule (mandatory)

- **Custom Rules**

Custom rules allow you to execute arbitrary **iptables** commands which are not otherwise covered by the firewall framework. The commands are executed after each firewall restart, right after the default rule settings have been loaded.

Black And White List | Port Forwards | **Custom Rules**

Firewall - Custom Rules

Custom rules allow you to execute arbitrary iptables commands which are not otherwise covered by the firewall framework. The commands are executed after each firewall restart, right after the default ruleset has been loaded.

```
# This file is interpreted as shell script.
# Put your custom iptables rules here, they will
# be executed with each firewall (re-)start.

# Internal uci firewall chains are flushed and recreated on reload, so
# put custom rules into the root chains e.g. INPUT or FORWARD or into the
# special user chains, e.g. input_wan_rule or postrouting_lan_rule.
#
# 2022-03-08 Fix restart Firewall will clear ddos mangle rules
/sbin/iptables -F
```


3.7 Diagnostics

Tools available in **Diagnostics** are explained below:

Tool	Description
Ping	To test the connectivity and measure the response time between the router and external IP addresses on the internet
Traceroute	To access information about the path that network traffic follows, including the number of hops and the response time of each hop
Nslookup	To query the Domain Name System (DNS) to obtain information about domain names, IP addresses, and DNS records

3.8 VTShark

The **VTShark** feature provides a flexible way to follow up and verify network issues. You can use wireshark to open and check the packets captured.



Description of the numbered areas

1. The interface from which the packets are captured (all interfaces are selected by default)
2. The measurement by which the data packets are captured (by seconds or by packet counts as explained below)
3. The filter for capturing the designated packets (more details are available at <https://www.tcpdump.org/manpages/pcap-filter.7.html> for advanced filtering)
4. Start the data capturing

Packets capturing by seconds and by packet counts:

Measurement	Description
Seconds	To specify a time duration for data capturing. For instance, you can input '10/20/30...' for the data capturing, which indicates that the capture will stop in 10/20/30 seconds.
	The system supports up to 500,000 packets for the time-based data capturing. The capture stops after reaching this limit, even if it has not reached the preset time duration.
Packets	To specify the count of packets for data capturing. For instance, you can input '100/200/500...' for the data capturing, which indicates that the capture will stop when 100/200/500 packets have been captured.
	The system supports up to 10 minutes (600 seconds) for the packet-based data capturing. The capture stops after reaching this limit, even if it has not reached the preset packet counts.

In the following scenario, the capture targets at all interfaces for the http packets from 'tcp port 80' for 30 seconds.

Start network capture

Interface	seconds, packets	Filter	Actions
any	30	seconds tcp port 80	Start capture

```


Tue Aug 22 01:50:05 UTC 2023 --- vtshark start to capture...
Tue Aug 22 01:50:05 UTC 2023 --- ifname: any
Tue Aug 22 01:50:05 UTC 2023 --- timeout : 30 seconds
Tue Aug 22 01:50:05 UTC 2023 --- packages : 500000
Tue Aug 22 01:50:05 UTC 2023 --- filter : tcp port 80
tcpdump: listening on any, link-type LINUX_SLL (Linux cooked v1), capture size 262144 bytes
521 packets captured
539 packets received by filter
0 packets dropped by kernel
Tue Aug 22 01:50:35 UTC 2023 --- vtshark capture finished...

```

Result

vtshark.result.pcap	Delete
---------------------	--------

Clicking the result will download it to the local directory and you can open it with wireshark.




3.9 User Management


As this feature may change system settings, you need log in with the root account (refer to [2.2](#) for the username and password) to enable it.

User management allows you to add new users or edit the existing users to assign different permissions to different roles.

To add a new user, click the button below the existing user information.



In the new page, you can create the user and enable certain features for the user.



Description of the numbered areas

1. Input a username
2. Select a group for the new user
3. Enable SSH access or not for the new user
4. Expand the menus to enable specific functions for the new user
5. Save the settings before you exit

After creating the user, it will be added to the user list. The **Edit** and **Delete** buttons behind a user allow you to enable/disable certain functions for this user or delete this user.




3.10 Customization

As certain features in this menu may change the system settings, you need log in with the root account (refer to [2.2](#) for the username and password) to enable the features.

3.10.1 Custom Program

Custom program allows users to upload scripts or programs (sh/bin) to the Router and run them at the startup.



Description of the numbered areas

1. Select a script to upload
2. Upload the script to the Router
3. When the script is uploaded successfully, the file name and file directory will be displayed here
4. Enable the script, and it will run automatically next time when the router starts up
5. If more than one script is uploaded, you can move any of them up or down to rearrange the script order, and edit/delete the scripts
6. Check the script log
7. **Save & Apply** the settings

3.10.2 IPK Installer

With IPK Installer, customers can install self-compiled IPK packages to the Router. Vantron industrial protocol packages are also uploaded from here.

The screenshot displays the IPK Installer web interface. It is divided into three main sections: Upload, Download, and Upload file list. The Upload section has a text input for the upload path (set to /usr/ipk_upload/), a 'Choose local file' button with a 'Choose File' sub-button, and an 'Upload' button. The Download section has a 'Download file' label, a 'Path on Route' input field, and a 'Download' button. The Upload file list section shows a status message: 'No packages removed. Installing plc_protocol (3.11.1-168) to root... Configuring plc_protocol. install success'. Below this is a table with columns: File name, Modify time, Attributes, Size, Remove, Install, and Stat. The table contains one entry: 'plc_protocol-R102_PKR-3.11.1-168_20230118.ipk' with a modify time of '2023-08-22 02:29:42', attributes 'rw-r--r--', size '3.1 MB', and 'Remove' and 'Install' buttons. The status is 'Installed'. Numbered callouts 1 through 5 are placed on the interface: 1 points to the 'Choose local file' button, 2 points to the 'Upload' button, 3 points to the 'Remove' button in the file list, 4 points to the status message, and 5 points to the 'Download' button.

File name	Modify time	Attributes	Size	Remove	Install	Stat
plc_protocol-R102_PKR-3.11.1-168_20230118.ipk	2023-08-22 02:29:42	rw-r--r--	3.1 MB	Remove	Install	Installed

Description of the numbered areas

1. Select an .ipk file from the local directory
2. Click **Upload** to upload the file to the device
3. You can delete or install the file after the .ipk file is uploaded
4. Install the file and wait a moment, there will be a prompt for the installation status
5. You can also input a file path on the device to download the specific file

3.10.3 Manufacturer Info Customization

Once you need to customize the manufacturer information for logging in the system, navigate to **Customization > Manufacturer Info Modify**, and select **OEM** from the **OEM Mode** drop-down list.

Description of the numbered areas


1. Select the **OEM** mode
2. Download the illustrative .tar file to the local directory and replace the files with your own as necessary
3. Select the target file from the local directory
4. Upload the file to the Router
5. The path of the file will be displayed here
6. Choose to enable the file or not for next startup
7. Select the type of the file
8. **Save & Apply** the settings

The three modes that customers can choose from the drop-down list based on needs are explained as follows.

Mode	Description
Vantron	All the information displayed in VantronOS will be Vantron-related
Standard	Some of the information displayed in VantronOS will be “Gateway” by default, and some information like the copyright will be left blank.
OEM	All the information displayed will be user tailored

3.10.4 DMP Agent

Gateways/routers are interfacing with BlueSphere GWM via DMP Agent. You can modify the settings of the DMP agent here.



Description of the numbered areas

1. Status of DMP Agent
2. Click **Clear Agent** before changing any configurations
- ▶ *Provided that the remaining prerequisites (refer to [2.5 Interfacing with Vantron Gateway Management Platform](#)) are met, the DMP Agent, once enabled, will run automatically when there is internet access. Clicking this button will disable DMP Agent, kill all the processes running at the background, and remove the Agent package from the original installation directory.*
3. Enable/Disable the Agent
4. You can customize the installation path of the Agent here (default path: '/usr/vtmdm_agent_c/')
5. Set up the download address of the Agent server (better to keep the default setting)
6. Internet server for public domain and download server for private domain
- ▶ *Factory reset of the Router will deactivate the device on the BlueSphere GWM platform. If you wish to activate it again on the GWM, please click **Clear Agent** in the VantronOS portal, then **enable** the agent and wait a moment to allow the device to come online on the BlueSphere GWM platform.*

3.11 Hardware

3.11.1 Ser2TCP


Serial to TCP provides an easy way to convert local serial data into Ethernet data and enables two-way communication with remote devices. Each conversion rule can be independently configured to server-side or client-side mode. You can also add, edit or delete a conversion rule on this page.

Ser2TCP
A tool that converts serial to TCP

Device	Enable/Disable	Baud Rate <small>The speed the device port should operate at.</small>		
/dev/ttyDemo	Disable	115200	Edit	Delete
/dev/ttyUSB0	Disable	115200	Edit	Delete
/dev/ttyUSB1	Disable	9600	Edit	Delete

Add

Serial list and details



Serial dev	Baud Rate	Status	Called by PID	Program name
/dev/ttyS0	57600	using	797	/bin/askfirst
/dev/ttyS1	9600	idle	null	null
/dev/ttyS2	9600	idle	null	null
/dev/ttyUSB0	9600	idle	null	null
/dev/ttyUSB1	9600	using	1311	/usr/sbin/cellularad
/dev/ttyUSB2	9600	idle	null	null

3.11.2 Ser2net Environment Setup and Verification

- Prerequisites
 - An R105 router
 - A Linux host computer (Ubuntu for demonstration here)
 - A USB to TTL serial adapter
 - A DuPont cable
 - Connect the serial port of the Router to the host computer as follows (refer to [1.5](#) for the connection, RS232 mode for demonstration here)



- Client mode

(1) Settings on VantronOS web interface

Ser2TCP
A tool that converts serial to TCP

Device	Enable/Disable	Baud Rate <small>The speed the device port should operate at.</small>		
/dev/ttyDemo	Disable	115200	Edit	Delete
/dev/ttyUSB0	Disable	115200	Edit	Delete
/dev/ttyUSB1	Disable	9600	Edit	Delete
	Enable	115200	Edit	Delete

Add

Serial list and details

Serial dev	Baud Rate	Status	Called by PID	Program name
/dev/ttyS0	115200	using	562	/sbin/askfirst
/dev/ttyS1	9600	using	26415	null
/dev/ttyS2	null	idle	null	null
/dev/ttyUSB0	9600	using	26415	null
/dev/ttyUSB1	9600	using	26415	null
/dev/ttyUSB2	9600	using	26415	null

Back or Refresh

Save & Apply Save Reset


Description of the numbered areas

1. Click **Add** to add a conversion rule
2. Select **Enable** from the drop-down
3. Set the Baud rate to 115200
4. Save the settings
5. Click **Edit** after the rule to access the advanced settings page

Advanced Setting		
Enable/Disable	Enable	①
Work mode	Work as client	②
Server and port	192.168.93.1:8888 <small>Eg: 177.6.6.6:678</small>	③
Device	/dev/ttyS1	④
Baud Rate	115200 <small>The speed the device port should operate at.</small>	⑤
Timeout	20 <small>Seconds</small>	⑥
Data Bits	8 bits	⑦
Parity	None	⑧
Stop Bits	1	⑨
Back or Refresh		Save & Apply Save Reset

Description of the numbered areas

1. **Enable** the rule
2. Select the **Work as client** mode
3. Input the server address and port number (Ubuntu host shall be the server, and port number is user-defined)
4. Select the serial device from the drop-down list (software node for RS232 port is /dev/ttyS1 as described in [1.5](#))
5. Select 115200 as the baud rate (the default value will be the one selected when setting up the rule)
6. Set a timeout value
7. Select “8 bits” for the data bit
8. Select “None” for parity
9. Select “1” as the stop bit

 **Save and Apply** above settings before you exit.

(2) The Ser2net process is running as follows:

```
uart2net -c -d 192.168.93.1 -p 8888 -t /dev/ttyS1 -b 115200 -a 8 -r none -s 1 -o 20
```

(3) Settings on the Ubuntu host


- Use microcom to access the serial port in terminal A (assume that the device name for the USB to TTL serial adapter is identified as /dev/ttyUSB1)

```
sudo microcom -p /dev/ttyUSB1 -s 115200
```

- Monitor the designated port (8888 as assigned in prior steps)

```
tcpudp_test tcp server:tcpudp_test -p 8888
```

- Input data in terminal A and receive in terminal B (the topology is as follows)



- Server mode

(1) Settings on VantronOS web interface

Ser2TCP
A tool that converts serial to TCP

Device	Enable/Disable	Baud Rate <small>The speed the device port should operate at.</small>		
/dev/ttyDemo	Disable	115200	Edit	Delete
/dev/ttyUSB0	Disable	115200	Edit	Delete
/dev/ttyUSB1	Disable	9600	Edit	Delete
	Enable	115200	Edit	Delete

Add

Serial list and details

Serial dev	Baud Rate	Status	Called by PID	Program name
/dev/ttyS0	115200	using	562	/sbin/askfirst
/dev/ttyS1	9600	using	26415	null
/dev/ttyS2	null	idle	null	null
/dev/ttyUSB0	9600	using	26415	null
/dev/ttyUSB1	9600	using	26415	null
/dev/ttyUSB2	9600	using	26415	null

Back or Refresh

Save & Apply Save Reset

Description of the numbered areas

1. Click **Add** to add a conversion rule
2. Select **Enable** from the drop-down
3. Set the Baud rate to 115200
4. Save the settings
5. Click **Edit** after the rule to access the advanced settings page

Advanced Setting		
Enable/Disable	Enable	1
Work mode	Work as server	2
Port	10	3
Protocol	Telnet	4
Device	/dev/ttyS0	5
Baud Rate	115200	6
Timeout	0	7
Data Bits	8 bits	8
Parity	None	9
Stop Bits	1	10

Back or Refresh Save & Apply Save Reset

Description of the numbered areas

1. **Enable** the rule
2. Select the **Work as server** mode
3. Input the port number (user-defined)
4. Select a protocol from the drop-down (**Telnet** for instance, see [3.11.3](#) for the difference between the protocols)
5. Select the serial device from the drop-down (software node of RS232 port is /dev/ttyS1 as described in [1.5](#))
6. Select 115200 as the baud rate (the default value will be the one selected when setting up the rule)
7. Set a timeout value
8. Select “8 bits” for the data bit
9. Select “None” for parity
10. Select “1” as the stop bit

Be sure to save above settings before you exit.

- (2) The Ser2net process is running as follows:

```
/usr/sbin/ser2net -n -c /tmp/ser2net.conf
```

(3) Settings on the Ubuntu host


- Use microcom to access the serial port in terminal A (assume that the device name for the USB to TTL serial adapter is identified as /dev/ttyUSB1)

```
sudo microcom -p /dev/ttyUSB1 -s 115200
```

- Monitor the designated port (10 as assigned in prior steps) in terminal B using Telnet protocol

```
telnet 192.168.19.207 10
```

- Terminals A and B can send and receive data in both directions (the topology is as follows)



3.11.3 Protocol comparison

Under the server mode, two protocols are available which are differentiated as below:

- 1) Raw: enables the port and transfers all data as-is between the port and the long integer.
- 2) Telnet: enables the port and runs the telnet protocol on the port to set up telnet parameters.

3.12 Services

3.12.1 Dynamic DNS

Dynamic DNS is a technology in domain name system (DNS) that automatically updates the content of Name Server, often in real time, with the active DDNS configuration of its configured hostnames, addresses or other information.

Input a name of the subdomain or root domain and click **Add** button, and you will be directed to the setup page of the dynamic DNS. Then you can edit the service as needed.

3.12.2 RC to PLC

For remote access and control of PLC devices via OpenVPN protocol, you will need two R105 routers and a Windows host computer ('Windows PC') that are on the same network. One router ('R1') is for building an OpenVPN server, and the other ('R2') is for connecting the OpenVPN server built by R1.

Prerequisites:

1. Prepare the R1, R2, Windows PC, and PLC device
2. Connect R1 and R2 to the same network via Wi-Fi or Ethernet
3. Install an OpenVPN client program (such as OpenVPN-2.5.2-I601-amd64.msi) and a PLC programming software (such as STEP7 depending on the device) on the Windows PC
4. Refer to [3.4.1 OpenVPN Server](#) to build an OpenVPN server in the **tap** working mode on R1 and download the .ovpn file
5. Connect the Windows PC to the OpenVPN server built by R1 via the OpenVPN client program
6. Connect R2 to the OpenVPN server built by R1 ([see below](#))
7. Connect the PLC device to a LAN port of R2 and set a static IP address for the PLC ([see details below](#))
8. Connect the PLC device to the Windows PC via Ethernet and control the PLC with the PLC programming software (STEP7)

VantronOS offers a platform for **connecting R2 to R1 and configuring the PLC and R2**. For other settings, please download the related software program and finish the setup.

Remote connect to PLC

Step 1: Upload key

General Setting Run log

Upload plc2down key file

Choose File No file chosen Connect

Restart core Connected, IPAddr: 10.8.0.2

Step 2 : Configure IP mapping

status	plc ip addr	virtual ip	Remarks
ready	172.18.1.132	10.8.0.6	

Add Delete

Description of the numbered areas


1. Download and save the .ovpn file after setting up the OpenVPN server on R1, then click this button to open the directory of the file
2. Click **Connect** to connect R2 to the OpenVPN server built by R1
3. After connection, an IP address assigned by the OpenVPN server will be displayed here
4. Input a static IP address for the PLC (on the same IP network as the LAN port of R2)
5. Input a virtual IP for the PLC (on the same IP network as the one assigned by the OpenVPN server and not occupied by other clients)

 Be sure to save above settings to allow them to take effect.

3.13 System

3.13.1 System

Apart from the device settings you might make in the previous sections, here you can configure your Router in more details, including host name, time zone, administrative password and so on.



Description of the numbered areas

1. Synchronize the router time with the browser (local) time
2. Change the name of the host
3. Select a time zone
4. Enable NTP online time adjustment
5. Start the NTP server (the Router is used as the NTP server)
6. NTP online time server

For log-related settings, click **Logging** tab next to the **General settings** tab.

System

Here you can configure the basic aspects of your device like its hostname or the timezone.

System Properties

General Settings **Logging** Language and Style

System log buffer size	64	1
	kiB	
External system log server	0.0.0.0	2
External system log server port	514	3
External system log server protocol	UDP	4
Write system log to file	/tmp/system.log	5
Console log output level	Error	6
Cron Log Level	Warning	7

Description of the numbered areas

1. Buffer size of the system log
2. Address of the log server
3. Port of the log server
4. Protocol used by the log server
5. Path of the file for the system log
6. Output level of the console log
7. Cron log level

3.13.2 Netlink Bandwidth Monitor (NBM) Setting

- General Settings

Netlink Bandwidth Monitor - Configuration

The Netlink Bandwidth Monitor (nlbwmon) is a lightweight, efficient traffic accounting program keeping track of bandwidth usage per host and protocol.

General Settings | Advanced Settings | Protocol Mapping

Accounting period (1) Day of month
Choose "Day of month" to restart the accounting period monthly on a specific date, e.g. every 3rd. Choose "Fixed interval" to restart the accounting period exactly every N days, beginning at a given date.


Due date (2) 1 - Restart every 1st of month
Day of month to restart the accounting period. Use negative values to count towards the end of month, e.g. "-5" to specify the 27th of July or the 24th of February.

Local interfaces (3)
☒ lan
☐ pptp
☐ wan
Only comtrack streams from or to any of these networks are counted.

Local subnets (4)
192.168.0.0/16
172.16.0.0/12
10.0.0.0/8
Only comtrack streams from or to any of these subnets are counted.

Description of the numbered areas

1. Set how long you would like the monitoring activities to be reported
2. Specify a date in a month for restarting another round of monitoring activities

 *Applicable when Day of month is selected in 1*

3. Select the interfaces to monitor
4. Local subnets

Under **Advanced Settings** tab, you can further set up the monitoring activities.

Netlink Bandwidth Monitor - Configuration

The Netlink Bandwidth Monitor (nlbwmon) is a lightweight, efficient traffic accounting program keeping track of bandwidth usage per host and protocol.

General Settings **Advanced Settings** Protocol Mapping

Maximum entries	1	10000	<small>The maximum amount of entries that should be put into the database, setting the limit to 0 will allow databases to grow indefinitely.</small>
Preallocate database	2	<input type="checkbox"/>	<small>Whether to preallocate the maximum possible database size in memory. This is mainly useful for memory constrained systems which might not be able to satisfy memory allocation after longer uptime periods.</small>
Compress database	3	<input checked="" type="checkbox"/>	<small>Whether to gzip compress archive databases. Compressing the database files makes accessing old data slightly slower but helps to reduce storage requirements.</small>
Stored periods	4	10	<small>Maximum number of accounting periods to keep, use zero to keep databases forever.</small>
Commit interval	5	24h - least flash wear at the expense of c▼	<small>Interval at which the temporary in-memory database is committed to the persistent database directory.</small>
Refresh interval	6	30s - refresh twice per minute for reason▼	<small>Interval at which traffic counters of still established connections are refreshed from netlink information.</small>
Database directory	7	/var/lib/nlbwmon	<small>Database storage directory. One file per accounting period will be placed into this directory.</small>

Description of the numbered areas

1. Set the maximum count of entries to store in the database ('0' for no limit)
2. Check the box to pre-allocate a database (more frequently applicable to devices with less memory space)
3. Check the box to compress the database
4. Maximum count of reporting periods to store ('0' for no limit)
5. Time interval for submitting the temporary database to the persistent database
6. Time interval for refreshing the traffic counters from the netlink information
7. Directory of the database

Protocol Mapping can be used to distinguish traffic types per host. Each mapping takes one line, with the first value being the IP protocol, the second value being the port number, and the third value being the name of the mapping protocol.

Netlink Bandwidth Monitor - Configuration

The Netlink Bandwidth Monitor (nlbwmon) is a lightweight, efficient traffic accounting program keeping track of bandwidth usage per host and protocol.

General Settings Advanced Settings **Protocol Mapping**

Protocol mappings to distinguish traffic types per host, one mapping per line. The first value specifies the IP protocol, the second value the port number and the third column is the name of the mapped protocol.

1	0	ICMP
2	0	IGMP
4	0	IP-In-IP
6	20	FTP
6	21	FTP
6	22	SSH
6	23	Telnet
6	25	SMTP
6	53	DNS
17	53	DNS
6	80	HTTP
17	80	QUIC
6	105	POP2
6	110	POP3
6	123	NTP
6	137	MAPBROG

3.13.3 Administration

On this page, you can reset the password for accessing the Router.


SSH Access

As this function might compromise the security of the network, you have to log in the web interface with a root account.


Step 1: Log out the interface by clicking **Logout** at the left bottom corner;

Step 2: Log in with the root account (root) and password (rootpassword);

Step 3: Navigate to **System > Administration**, and enable dropbear;




Description of the numbered areas

1. Select a port to access (LAN by default)
 *When “unspecified” is selected, all the ports will be monitored.*
2. Specify a port for monitoring (port 22 by default)
3. Allow SSH password authentication
4. Add SSH-Keys for public key authentication


Step 4: Open an SSH client (PuTTY or MobaXterm recommended) in the Windows host;

Step 5: Input the host name or IP address (LAN port address by default: 172.18.1.1), keep the default port No. (22) unchanged, and select **SSH** for the connection type;

Step 6: Set the session name and **Save**, keep the other settings unchanged, then click **Open**;




Step 7: Log in with the root account and password (same as those in the prior step), and start an SSH remote session.



3.13.4 Terminal

After navigating to **System > Terminal**, users can click **enable** from the drop-down box under the **Setting** tab and **Save & Apply** the setting to enable the web terminal for router debugging.



Setting

Terminal

Terminal not run!

Enable/Disable: disable

Interface:


Back or Refresh

Save & Apply Save Reset

After the web Terminal is enabled, the **Terminal** tab will be available next to the **Setting** tab.

Login name: root

Login password: rootpassword (invisible while typing)



Terminal Setting

Terminal

VantronOS-8313 login: root
Password:


BusyBox v1.31.1 () built-in shell (ash)

V200R003.F0000-03 Built at 2022-02-17 08:17:10

root@VantronOS-8313:~#

3.13.5 Mount Points


You can enable/disable automount and check the mounting information here.



Description of the numbered areas

1. Disable/Enable automatic mount
2. File path on the Router
3. Mount point
4. Available space in the mount point
5. Space used in percentage
6. If you have previously mounted a file to the device, you can manually unmount the file here

To manually mount a file, click the **Click Disable Automount** button first and then proceed with the settings.



Mount Points

Global Settings

Automount Filesystem [Click Enable Automount](#)

Mount Detect [Mount Detect](#) ①
Find enabled configurations and mount

Mounted file systems

Filesystem	Mount Point	Available	Used	Unmount
/dev/root	/rom	0.00 B / 15.00 MB	100% (15.00 MB)	
tmpfs	/tmp	109.80 MB / 122.27 MB	10% (12.47 MB)	
/dev/mtdblock10	/overlay	17.91 MB / 23.62 MB	24% (5.72 MB)	
overlayfs:/overlay	/	17.91 MB / 23.62 MB	24% (5.72 MB)	
tmpfs	/dev	512.00 KB / 512.00 KB	0% (0.00 B)	

Mount Points

Mount Points define at which point a memory device will be attached to the filesystem

Enabled	Device	Mount Point	Filesystem	Options	Root
This section contains no values yet					

[Add](#) ②

Description of the numbered areas

1. Detect the available mount points
2. Click **Add** to add a mount point

Click the **Edit** button behind the newly added mount point for more settings.

Mount Points - Mount Entry

Mount Entry

[General Settings](#) [Advanced Settings](#)

Enable this mount ③ ☒

UUID ④
If specified, mount the device by its UUID instead of a fixed device node

Mount point ⑤
Specifies the directory the device is attached to

3. Check the box to enable the mount point after creation
4. Select the UUID of the device
5. Select the mount point

Then click the **Advanced Settings** tab to access advanced settings.

Mount Points - Mount Entry

Mount Entry

General Settings **Advanced Settings**

Filesystem 6
The filesystem that was used to format the memory (e.g. ext3)

Mount options 7
See "mount" manpage for details

Back or Refresh 8 **Save & Apply** **Save** **Reset**

6. Select the file system for formatting the memory
7. Input the mount options
8. Save the settings and click the **Back or Refresh** button to return to the general settings

Mount Points

Mount Points define at which point a memory device will be attached to the filesystem

Enabled	Device	Mount Point	Filesystem	Options	Root	
<input checked="" type="checkbox"/>	UUID: eac1bc10-b8d7d9c7-cc627f98-1137c9b6	/overlay	squashfs	defaults	overlay	Edit Delete

The mount point is created as above.

3.13.6 Backup/Flash Firmware

On this page, you can backup/restore parameters, restore factory settings (clear user settings), and update firmware from the local or with OTA.

OTA Upgrade

OTA Firmware Update Backup/Restore Configuration

Upgrade firmware with OTA

Device model: VT-M2M-R105

Local version: V200R004F0000-10 The latest version of the cloud: **Failure** **Refresh** 1

Upgrade firmware with OTA

Upgrade and reset 2 Upgrade and keep setting 3

Description of the numbered areas

1. Refresh the cloud version to the latest (internet access required)
2. Upgrade the Router and reset to default settings
3. Upgrade the Router and keep the user settings unchanged

If the version from the cloud is shown **Failure**, please check if the Router has internet access.

Firmware Update

OTA **Firmware Update** Backup/Restore Configuration

Flash new firmware image

Upload a sysupgrade image here to replace the running firmware form local.(Device model: **VT-M2M-R105**)

Keep settings: ☒ 1

Image: 2 XOS_WebU...0000-05.xos

4

Uploading 31% 5.8M/18.9M

Description of the numbered areas

1. Check the box to keep the user settings while upgrading the device (not recommended)
2. Select the firmware from the local directory
3. Click the button to upload the firmware
4. Upload progress of the package

When the detailed information of the firmware is displayed, check if the firmware is correct, then click **Proceed** to start the upgrading;

OTA **Firmware Update** Backup/Restore Configuration

Flash Firmware - Verify

The flash image was uploaded. Below is the checksum and file size listed, compare them with the original file to ensure data integrity.
Click "Proceed" below to start the flash procedure.

- Checksum
 - MD5: d8548f6831e1dd6f1bc890835e650e8b
 - SHA256: db5383e4195e075ab1aa7b85a5b68497f7f878023b779b014c207dc57c21d231
- Size: 19.10 MB
- Configuration files will be kept

It will take some time for the upgrade and DO NOT power off the Router when firmware upgrading is in process;


System - Flashing...

The system is flashing now.
DO NOT POWER OFF THE DEVICE!
Wait a few minutes until you try to reconnect. It might be necessary to renew the address of your computer to reach the device again, depending on your settings.
Waiting for changes to be applied...

The login page will be refreshed once the upgrading finishes and you can login to check the firmware version on the homepage.



Under the **Backup/Restore** tab, you can download the backup package of your settings, including configuration files and pre-set folders, restore the factory settings of the Router, and upload the backup package saved before.



Description of the numbered areas

1. Click the button to back up the system configurations (include only the configuration files and preset files other than client files or programs)
2. Factory reset the Router (user configurations will be cleared)
3. Select the backup file from the local directory to restore the backup settings
4. Upload the file

Under the **Configuration** tab, you can customize the configuration files or directories to be retained during the upgrade.

Backup file list

OTA Firmware Update Backup Restore **Configuration**

This is a list of shell glob patterns for matching files and directories to include during sysupgrade. Modified files in /etc/config/ and certain other configurations are automatically preserved.

Show current backup file list Open list... 3

```
## This file contains files and directories that should
## be preserved during an upgrade.
# /etc/example.conf
/etc/bootscript/
```

1

2 **Submit** **Reset**

Description of the numbered areas

1. Input the configuration file or directory to be retained during the upgrade
2. Click **Submit** to confirm the setting
3. Open the list of configuration files kept during the upgrade

3.13.7 Reboot

Make sure you don't have any ongoing process before rebooting the Router.

3.14 Logout

You will exit the web interface with a click on the **Logout** tab. If you need make changes to any of your settings, you can log in the web again with default password: **admin**. Make sure you have saved the changes before logout.

CHAPTER 4 DISPOSAL AND PRODUCT WARRANTY

4.1 Disposal

When the device comes to end of life, you are suggested to properly dispose of the device for the sake of the environment and safety.

Before you dispose of the device, please back up your data and erase it from the device.

It is recommended that the device is disassembled prior to disposal in conformity with local regulations. Please ensure that the abandoned batteries are disposed of according to local regulations on waste disposal. Do not throw batteries into fire or put in common waste canister as they are explosive. Products or product packages labeled with the sign of “explosive” should not be disposed of like household waste but delivered to specialized electrical & electronic waste recycling/disposal center.

Proper disposal of this sort of waste helps avoid harm and adverse effect upon surroundings and people’s health. Please contact local organizations or recycling/disposal center for more recycling/disposal methods of related products.

4.2 Warranty

Product warranty

VANTRON warrants to its CUSTOMER that the Product manufactured by VANTRON, or its subcontractors will conform strictly to the mutually agreed specifications and be free from defects in workmanship and materials (except that which is furnished by the CUSTOMER) upon shipment from VANTRON. VANTRON's obligation under this warranty is limited to replacing or repairing at its option of the Product which shall, within **24 months** after shipment, effective from invoice date, be returned to VANTRON's factory with transportation fee paid by the CUSTOMER and which shall, after examination, be disclosed to VANTRON's reasonable satisfaction to be thus defective. VANTRON shall bear the transportation fee for the shipment of the Product to the CUSTOMER.

Out-of-Warranty Repair

VANTRON will furnish the repair services for the Product which are out-of-warranty at VANTRON's then-prevailing rates for such services. At customer's request, VANTRON will provide components to the CUSTOMER for non-warranty repair. VANTRON will provide this service as long as the components are available in the market; and the CUSTOMER is requested to place a purchase order up front. Parts repaired will have an extended warranty of 3 months.

Returned Products

Any Product found to be defective and covered under warranty pursuant to Clause above, shall be returned to VANTRON only upon the CUSTOMER's receipt of and with reference to a VANTRON supplied Returned Materials Authorization (RMA) number. VANTRON shall supply an RMA, when required within three (3) working days of request by the CUSTOMER. VANTRON shall submit a new invoice to the CUSTOMER upon shipping of the returned products to the CUSTOMER. Prior to the return of any products by the CUSTOMER due to rejection or warranty defect, the CUSTOMER shall afford VANTRON the opportunity to inspect such products at the CUSTOMER's location and no Product so inspected shall be returned to VANTRON unless the cause for the rejection or defect is determined to be the responsibility of VANTRON. VANTRON shall in turn provide the CUSTOMER turnaround shipment on defective Product within **fourteen (14) working days** upon its receipt at VANTRON. If such turnaround cannot be provided by VANTRON due to causes beyond the control of VANTRON, VANTRON shall document such instances and notify the CUSTOMER immediately.

Appendix Regulatory Compliance Statement

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate this equipment.

IC Statement

This device complies with ISED's licence-exempt RSSs. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be chosen so that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. Le dispositif ne doit pas produire de brouillage préjudiciable, et
2. Ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radio électrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.