

3DMAKERPRO

- **∮** @3DMakerProCares
- (ii) @official3DMakerPro
- @3DMakerPro
- https://store.3dmakerpro.com/
- service@3dmakerpro.com

JimuMeta

- **€** @JimuMeta
- @JimuMeta
- fig. https://www.jimumeta.com/
- service@jimumeta.com

Download latest **JMStudio** from

https://forum.jimumeta.com/home/help/download.html


Get latest Manual from

https://forum.jimumeta.com/home/help/manual.html










Plug one side of the data transmission cable (as it's showing Device Cable) into the scanner, another into the computer USB port and power adapter;

The turntable cable is for powering up the turntable.



* Device Cable





Plug the device cable into the port of the scanner, make sure the red dot is lined up with the groove on the port;

To upply the cable, may be belowered the bushing (as marke).

To unplug the cable, move backwards the bushing (as marked with the red triangles) and pull out the cable directly.


* Turntable Cable





The turntable can be powered up by connecting it to the computer or the power adapter with the turntable cable.

PACKING LIST



- * Product images are for illustrative purposes only.
- * 1234 Not included in the Standard Combo.

Operating System Requirement Minimum Intel Core i5 8th, 16GB RAM, MX250 GPU with 2GB VRAM Recommended Intel Core i7 8th, 16GB RAM, NVDIA1060 GPU with 4GB VRAM To prevent antivirus software from blocking the driver,

please uninstall the antivirus software.