


## Audio Amp SHIM (3W Mono Amp)

SKU PIM541



A super-simple, slimline way to hook up a 3W speaker to your Raspberry Pi! Output punchy digital I2S audio while leaving your GPIO pins conveniently accessible. SHIM is an old Yorkshire term meaning 'Shove Hardware in Middle' - it is used for Raspberry Pi add-ons that are designed to be sandwiched between your Pi and a HAT or mini HAT. This one has a **clever friction fit header** which slips handily over your GPIO pins and is **easily removable** - great for prototyping.

The **MAX98357A combined DAC / amplifier chip** takes high quality digital audio from your Pi and amplifies so it can be used with an unpowered speaker. The **push-fit connectors** make it straight-forward to connect your speaker, whether it is a bookshelf or floor-standing speaker, the speaker in an old radio, or a tiny mini speaker.

Because Audio Amp SHIM adds no extra bulk to your Pi it's perfect for building into a compact enclosure - you could use it to make a tiny MP3 player to play local files or stream from online services, give a vintage radio the ability to play digital radio streams or incorporate bleep noises into your very own retro handheld. It is also a handy way to add an audio output to your Pi Zero or Pi 400.

Please note that **Raspberry Pi and speakers are not included** with this board.

### Features

- MAX98357A DAC / amplifier chip
- Mono 3W audio out
- Push-fit speaker terminals
- SHIM-format board with friction-fit connectors
- 2x mounting holes (M2.5) for if you want to secure everything together with bolts.
- Fully assembled.
- No soldering required (unless you are using a Pi that comes without a header) \*
- Compatible with all 40-pin header Raspberry Pi models
- Schematic

\* Note that variation in manufacturing tolerances on both headers and boards can affect the tightness of the friction fit. If you find that yours is not making a good connection, you could try bending the two rows of GPIO pins away from each other very slightly to improve the fit.

To ensure a robust connection, we would suggest soldering the SHIM to your Pi's GPIO pins (or a socket header) when you come to install it in your final project.

## Software

The easiest way to get everything set up is to use the [Pirate Audio software and installer](#) which configures I2S audio, as well as installing Mopidy and our custom Pirate Audio plugins.

Here is how to get started:

1. Set an SD card up with the latest version of Raspberry Pi OS.
2. Connect to Wi-Fi or a wired network.
3. Open a terminal and type the following:

```
git clone https://github.com/pimoroni/pirate-audio
cd pirate-audio/mopidy
sudo ./install.sh
```

4. Reboot your Pi

You can find more detailed instructions here: <https://github.com/pimoroni/pirate-audio/tree/master/mopidy> or more info in the [Getting Started with Pirate Audio](#) tutorial.

Alternatively, if you would rather not install all the Mopidy stuff, you can set Audio Amp SHIM as your default ALSA device in Raspberry Pi OS by adding the following line to your `/boot/config.txt` file: `dtoverlay=hifiberry-dac`

If you are using a Pi that has an audio jack, you might also need to disable onboard audio by adding a `#` to the beginning of the following line (this can help applications find the correct audio device automatically)

```
#dtparam=audio=on
```

## Notes

- Dimensions: 63.3 x 15.2 x 5.4mm (L x W x D, including speaker connector)
- You can use an Audio Amp SHIM with HATs and mini HATs without a booster header, as long as they don't have any chunky components on the underside (it's a good idea to check there are no metal components on the underside of your HAT that touch the metal components on the top of the SHIM).
- If you want to use one with a Pibow Coupé case (either for the Zero / Zero W or Pi 4), then you will need to use a booster header to raise it up a little.
- If you are planning to use Audio Amp SHIM to add an audio output to your Pi 400, you will also need a booster header. If you are plugging it directly into the back of a Pi 400, bear in mind that the SHIM should be upside down, with the mounting holes at the bottom. Alternatively, you could plug it in via a Flat HAT Hacker (in which case you will not need a booster header or to plug anything in upside down).
- Maximum wire size for the push fit connectors is 0.75mm<sup>2</sup> (1mm diameter, 18AWG). You will need tinned ends on your speaker wires, so that they are stiff enough to push into the connectors (all the speakers we sell have tinned wires).
- Audio Amp SHIM uses GPIO 18, 19, and 21 (as well as 3.3v, 5v and ground). If you are planning to use it in conjunction with other boards, you will need to check for pin conflicts using [pinout.xyz](http://pinout.xyz).